



USER MANUAL – EN
Trampoline Froggy PRO Safety Net



*The photo is for illustration purposes only.

CONTENTS








- PARTS LIST 3
 - DIAGRAM OF PARTS 3
- ASSEMBLY INSTRUCTIONS 4
- GENERAL SAFETY ADVICE 5
 - USING THE SAFETY NET 6
 - SAFETY INFORMATION 6
 - CARE & MAINTENANCE 7
- TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS 7

READ THIS MANUAL FIRST!

PARTS LIST

Reference Number	Description	183/244/305 cm	366/397/430 cm	458/488 cm
1	Upper pole A	6 pcs	8 pcs	12 pcs
2	Upper pole B	6 pcs	8 pcs	12 pcs
3	Bar Spacers	12 pcs	16 pcs	24 pcs
4	Curved Washers	12 pcs	16 pcs	24 pcs
5	Screws	12 pcs	16 pcs	24 pcs
6	Nuts	12 pcs	16 pcs	24 pcs
7	Safety Net	1 pc	1 pc	1 pc


DIAGRAM OF PARTS

Upper pole A	
Upper pole B	
Bar spacers	
Curved washers	
Screws	
Nuts	
Safety net	

WARNING: READ THESE INSTRUCTIONS PRIOR TO ASSEMBLY.


ASSEMBLY INSTRUCTIONS

STEP 1: Mount the upper pole A onto the vertical leg using parts (3), (4), (5) and (6).




STEP 2: Spread the safety net (7) on the trampoline's jumping mat. Make sure the pockets meant to hold the upper pole A face upwards. Align the pockets with the upper pole A.

Place the upper pole B (2) in the pockets of the safety net.




STEP 3: Connect parts (2) and (1).



Pull the upper foam padding down the individual poles, until it lies on the lower foam padding.

Carefully and evenly pull down the safety net (7).

STEP 4: Fasten the safety net to the reverse side of the trampoline. Hook the elastic fastening ties to the inner straps of the jumping pad. However, take care that no greater openings occur, so that the users won't jump out of the net.



STEP 5: Close the zip on the safety net (7) and hook it to both security fasteners.

IMPORTANT WARNING!!

YOU SHOULD GO BACK NOW AND STRETCH ALL THE ATTACHMENT HOOKS TIGHT AND DOUBLE CHECK TO SEE WHETHER YOU HAVE FASTENED THE SCREWS AND BOLTS ENOUGH, SO THAT THE SAFETY NET STANDS STIFF. OTHERWISE, THE SAFETY NET WILL NOT FUNCTION PROPERLY.

THE ASSEMBLY IS NOW COMPLETE.

GENERAL SAFETY ADVICE

- Please read this manual before first use and keep it for future reference.
- Ensure that the trampoline safety net has been assembled correctly, as per the instructions in this manual.
- Children **MUST NEVER** use the trampoline unless supervised by a responsible adult knowledgeable about trampoline use.
- Children **MUST NEVER** be left unattended inside the safety net at any time.
- **ALWAYS** follow the safety warnings stated in the trampoline instructions while using the safety net.

- DO NOT climb, swing or intentionally jump onto the panels or poles of the safety net.
- If the safety net material becomes damaged, refrain from using it.
- The safety net is ONLY intended to be used to reduce the risk of an injury from falling off the trampoline.
- DO NOT let children take items or toys with them onto the trampoline.
- Please read and refer to other warnings and use the information in the trampoline and safety net instructions before use.

Please retain this manual for future reference.

USING THE SAFETY NET

- **Assembly Information:** This safety net must be assembled by an adult. They must be assembled exactly in accordance with the assembly instructions. Enlisting the aid of a helper will make assembly easier. This safety net contains small parts and is not suitable for children under 3 years old. Please take an inventory of all parts before assembly. Should there be any missing parts; the equipment must not be used until replacement parts have been fitted.
- **Location:** Your trampoline must be placed on a flat and level surface which is well lit. Under no circumstances should it be positioned on a hard surface such as concrete or asphalt, unless the ground under the trampoline has free-space of 2 meters surrounding the trampoline and is covered with a safety surface as well as a 7-meter clearance above the trampoline. Examples of suitable surfaces are grass, sand or a mat intended for this trampoline. It is important not to place or store anything under your trampoline. Please also read the user manual of your trampoline.

WARNING: The safety net should be replaced after a year.

SAFETY INFORMATION

- This safety net is designed and made for domestic use only by people over 6 years of age. It is not a propelling device. It is designed as a safety net to control entry and exit to and from the trampoline and to allow jumpers to gain confidence, balance, coordination and agility without the fear of falling off the trampoline, where injury could occur.
- Adult supervision of children: Children should always be supervised while they are playing on the trampoline fitted with a safety net and should be instructed not to use it in an inappropriate or hazardous manner. In particular be aware of:
 - The objects children bring into the safety net
 - Children's activities inside the safety net
 - Conditions inside the safety net when children are using it
 - The way children get into and out of the safety net
- Children should not wear bicycle helmets while playing on the trampoline.
- The frame of your trampoline is made of steel and it will conduct electricity. No electrical equipment (lights, heaters, extension cords, household appliances, etc.) should be permitted in or on the safety net under any circumstances to avoid the risk of electrocution.
- Never allow more than one person to use the trampoline at a time. Multiple users may collide with each other and this can result in serious injury.
- As your trampoline mat is raised off the ground, there is the risk of a fall when exiting the trampoline through the door of the safety net. Children should be assisted when entering and exiting the safety net to reduce their risk of falling.
- Only the door of the trampoline safety net should be used to enter or exit the safety net.

- Weather conditions: Special care should be taken as weather conditions change. In particular, surfaces can become slippery in wet weather and tongues and lips can stick to the metalwork at subzero temperatures. In warmer weather, parts can become hot, and temperatures should be regularly checked during use, especially the temperature of metal parts.

CARE & MAINTENANCE

- It is vital that the equipment is checked for wear, damage or missing parts regularly and often by an adult. The complete product should be checked at least once a month, with particular attention being paid to all connections and fastenings. If any parts exhibit signs of wear or tear, they may need to be replaced. Failure to do this may result in the product malfunctioning and causing injury.
- The product must not be used until properly and fully installed and checked. Galvanized bars may require occasional maintenance. If surface rust appears, it should be removed with either a wire brush or coarse sandpaper, and the area should be coated with a non-toxic paint.
- To avoid damage to the safety net, do not allow pets or other animals inside. Their claws and teeth can damage the netting or the trampoline mat.
- Make sure that no bonfires are lit close enough to threaten your trampoline and safety net. In windy conditions, sparks and embers can travel significant distances and burn holes in both the safety net netting and the trampoline mat.
- Any large trampoline, with or without a safety net, can be blown around in high winds and cause injury or damage. We recommend that the safety net should be removed under these conditions and stored in a dry place.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated hereunder determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 40/1964 Coll. Civil Code, Act No. 513/1991 Coll., Commercial Code, and Act No. 634/1992 Coll., Consumer Protection Act, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Borivojova Street 35/878, Prague 13000, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions to the extent specified in the Commercial Code.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.



SEVEN SPORT s.r.o.

Registered Office:	Borivojova 35/878, 130 00 Praha 3, Czech Republic
Headquarters:	Delnicka 957, 749 01 Vitkov, Czech Republic
Warranty & Service Centre:	Cermenska 486, 749 01 Vitkov, Czech Republic
CRN:	26847264
VAT ID:	CZ26847264
Phone:	+420 556 300 970

E-mail: eshop@insportline.cz
reklamace@insportline.cz
servis@insportline.cz
Web: www.insportline.cz

SK

INSPORTLINE s.r.o.

Headquarters, Warranty & Service centre: Elektrická 6471, 911 01 Trenčín, Slovakia

CRN: 36311723

VAT ID: SK2020177082

Phone:

+421(0)326 526 701

E-mail:

objednavky@insportline.sk

reklamacie@insportline.sk

servis@insportline.sk

Web:

www.insportline.sk

Date of Sale:

Stamp and Signature of Seller: