



USER MANUAL – EN

IN 24174 Child seat for bike frame inSPORTline Mousino



SAFETY INSTRUCTIONS

- Read the manual carefully before use and assembly and keep it for future reference.
- Prior to use, make sure that all screws are tightened, and the seat and handles are properly fastened.
- The child must have personal protective equipment (protectors, helmet, etc.)
- The driver of the bicycle must be over 18 years of age.
- Check the condition of the bike before use.
- No part of the child's body or clothing should interfere with the moving parts of the bike.
- Do not modify the product.
- Never leave a child unattended in a seat.
- Do not use the product if it is damaged or has sharp edges.
- Never exceed the maximum load capacity of the entire bike.
- Always place the child's feet on risers with straps and make sure they are not damaged (you must always fasten the straps even when you are not transporting the child).
- Ride carefully, the balance of the bike may be affected by the child and the seat.
- Use warm water and soap to clean the saddle and soft parts, never use solvents.
- Respect the rules of the road, wear a helmet (you and the child) and ride carefully.
- Do not expose the seat to high temperatures and make sure that the seat is not hot before use.
- If your kid cannot sit properly, do not transport them.

- If parts of the seat are damaged or broken, replace the seat.
- Never transport goods to the seat, use a carrier. If you are transporting a child, the goods must be placed at the other end of the bike.
- If the seat is in place, make sure there is enough space between the child's and adult's legs. Check that the functionality of the wheel is not impaired (eg pedals, brakes, clothing ...).
- Never transport 2 children in one seat at a time.
- Never transport a bike on the roof rack of a car with a seat on the bicycle.
- Regularly check the seat and its attachment.
- Protect your child with suitable clothing while driving.
- Never use a seat on a motorcycle, racing bikes, suspension wheels, folding bikes.
- Make sure that there are no frayed brake cables anywhere on the bike that could injure your child.
- Maximum load: 32 kg
- Age: 2 - 7 years

HANDLE ASSEMBLY



Make sure all parts are present. The handles are divided into 3 parts.




The handle brackets are marked A and B.



Loosen the screws on both sides of the brackets.



Holes A are for attaching the handlebars. Use suitable inserts according to the diameter of the handlebars.



First, attach the handlebar brackets to the bike handlebars. Then attach the handlebar to the brackets. Tighten the screws.



SEAT ASSEMBLY

Loosen the seat bracket bolt. Extend the bracket to the width of the frame.





Remove the marked part by unscrewing the nut.



Place the bracket on the frame and find a suitable position.



<p>Tighten the 2x screws on both upper sides. Set the appropriate bracket angle.</p>	
<p>Press the bracket and tighten the upper bolt.</p>	
<p>The pedals are divided into 3 parts. Both sides of the rod are the same, marked for illustration only. Screw the nuts into one third of the rod on side A. Slide side B into the hole in the bracket. Slide side A into the bracket.</p>	
<p>Screw each nut onto the side of the seat bracket. Make sure that each side is the same length.</p>	

<p>The pedals are composed of straps and footrests.</p> <p>The side of the strap with two holes is on the outside and is used to adjust the length according to the size of the foot.</p> <p>The open part of the footrest is used to slide the pedals onto the pedal rod.</p> <p>The closed part of the footrest is the outer part.</p>	
<p>Slide the pedals onto the pedal rod and tighten the nuts.</p>	
<p>Reattach the marked part that you removed in step 2.</p> <p>Select the correct hole according to the frame.</p>	
<p>Attach the seat to the seat holder, tighten the nut.</p>	

Prior to use, make sure that all parts are correctly assembled and tightened.



ENVIRONMENT PROTECTION

After the product lifespan expired or if the possible repairing is uneconomic, dispose it according to the local laws and environmentally friendly in the nearest scrapyard.

By proper disposal you will protect the environment and natural sources. Moreover, you can help protect human health. If you are not sure in correct disposing, ask local authorities to avoid law violation or sanctions.

Don't put the batteries among house waste but hand them in to the recycling place.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated here under determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Strakonická street 1151/2c, Prague 150 00, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

Batteries

6-month battery warranty – we guarantee that battery's nominal capacity does not fall below 70% of its total capacity within 6 months of the product's sale.

The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints, wear of brake pads/blocks, chain, tires, cassette/multi wheel etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

**CZ
SEVEN SPORT s.r.o.**

Registered Office: Strakonická 1151/2c, Praha 5, 150 00, ČR
Headquarters: Dělnická 957, Vítkov, 749 01
Warranty & Service: Čermenská 486, Vítkov 749 01

CRN: 26847264
VAT ID: CZ26847264

Phone: +420 556 300 970
E-mail: eshop@insportline.cz

reklamace@insportline.cz
servis@insportline.cz

Web: www.inSPORTline.cz

SK
inSPORTline s.r.o.

Headquarters, warranty & service center: Električná 6471, Trenčín 911 01, SK

CRN: 36311723

VAT ID: SK2020177082

Phone: +421(0)326 526 701

E-mail: objednavky@insportline.sk
reklamacie@insportline.sk
servis@insportline.sk

Web: www.inSPORTline.sk