




USER MANUAL – EN

IN 10895 Exercise Bike inSPORTline inCondi UB20m



Made in PRC

CONTENTS

SAFETY INSTRUCTIONS..... 3

ASSEMBLY 5

EXPLODED VIEW 8

PARTS LIST 9

RESISTANCE ADJUSTMENT 11

LEVELLING THE BIKE..... 11

HOW TO FOLD 11

HOW TO ADJUST 12

CONTROL PANEL OPERATION 13

iBIKING+ INSTRUCTIONS 14











TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS..... 19

SAFETY INSTRUCTIONS


Before you undertake any program of exercise that will increase cardiovascular activity please be sure to consult with your doctor. Frequent strenuous exercise should be approved by your doctor and proper use of your product is essential. Please read this manual carefully before commencing assembly of your product or starting to exercise.

- Please keep all children away from exercise products when in use. Do not allow children to climb or play on them when they are not in use.
- For your own safety, always ensure that there is at least 0.6 meter of free space in all directions around your product while you are exercising.
- Regularly check to see that all nuts, bolts and fittings are securely tightened. Periodically check all moving parts for obvious signs of wear or damage.
- Clean only with a damp cloth, do not use solvent cleaners. If you are in any doubt, do not use your product, but contact CUSTOMER SUPPORT.
- Before use, always ensure that your product is positioned on a solid, flat surface. If necessary, use a rubber mat underneath to reduce the possibility of slipping in use.
- Always wear appropriate clothing and footwear such as training shoes when exercising. Do not wear loose clothing that could become caught or trapped during exercise.
- Your product is intended for use in clean dry conditions. You should avoid stocking in excessively cold or damp places as this may lead to corrosion and other related problems that are outside our control.
- **WARNING!** A heart rate monitor may not be accurate. Overloading during training may cause serious injury or death. If you feel any discomfort, immediately stop the exercise!
- Maximum user weight is 100 kg
- Class - HC (according to EN ISO 20957) for home use
- It is NOT suitable for therapeutic purposes

CHECK LIST


<p>Main Frame (7), Rear Frame (2)</p>  <p>Tools</p> 	<p>Saddle (24)</p>  <p>Saddle Support (6)</p> 	<p>Exercise monitor (16), Handlebar (1)</p> 
<p>Front Stabilizer (9)</p>  <p>Rear Stabilizer (8)</p> 	<p>Adjuster Knob (26)</p>  <p>Locking Pin (3)</p> 	
<p>Pedal (29L), Pedal (29R)</p> 		

HARDWARE:




ASSEMBLY


STEP 1: Assemble Rear & Front Stabilizer, Pedal (L/R)




STEP 2: Assemble Saddle




STEP 3: Assemble Handlebar & Exercise Monitor



Complete!



EXPLODED VIEW



PARTS LIST

Part No.	Description	Q'ty
1	Handlebar	1
2	Rear Frame	1
3	Locking Pin	1
4	M5*10 Screw	2
5	Oval Line plug	3
6	Saddle Support	1
7	Main Frame	1
8	Rear Stabilizer	1
9	Front Stabilizer	1
10	Crank (R&L)	2
11	Main Shaft	1
12	Lower Drive Wheel Shaft	1
13	Magnetic Bracket	1
14	Round Steel	2
15	Handle Grip Foam	2
16	Exercise Monitor	1
17	Pulse Sensor Pad	2
18	Chain Cover (U)	1
19	Tension Control knob	1
20	Eva Sticker	1
21	Control line	1
22	Pulse Sensor Wire	2
23	Gear piece	2
24	Saddle	1
25	Saddle Stem Insert	1
26	Seat Adjustment Knob	1
27	Adjustable Hex End Cap	2
28	End Cap	2
29	Pedal (R&L)	2
30	Chain Cover (R&L)	2
31	Pulley Brush	2
32	Flywheel	1
33	Pulley Bracket	1
34	Lower Drive Wheel	1
35	Upper Drive Wheel Shaft	1

36	Upper Drive Wheel	1
37	Sensor Bracket	1
38	Magnet	6
39	Crank Guard Trim	2
40	Pulley	4
41	Waved Washer	5
42	Spring Washer	4
43	M4*20mm Self-tapping Screw	5
44	M5*15mm Screw	3
45	M6*12mm Allen Bolt	4
46	M5*50mm Screw	1
47	Drive Belt 230J	1
48	Drive Belt 220J	1
49	Spring	1
50	M8*20 mm Allen Bolt	2
51	M8 x 65 mm Carriage Bolt	4
52	M6*40 mm Screw	2
53	M6*15 mm Screw	8
54	M4*20 Self-tapping Screw	4
55	M10 Nut	2
56	M6 Curved Washer	2
57	M6 Flat Washer	2
58	Flat Washer	1
59	Sensor Wire	1
60	M8 Flat Washer	3
61	M8 Dome Nut	4
62	M8 Nylon LockNut	3
63	Flat Washer	2
64	Outer Brush	4
65	Inner Brush	2
66	Lock Ring	1
67	Bearing	1
68	Flat Washer	1
69	M10 Nylon LockNut	1
70	Pulley	2
71	M8 Curved Washer	4
72	M8 Spring Washer	4
73	M6 Spring Washer	4

74	Handlebar cap	2
----	---------------	---


RESISTANCE ADJUSTMENT

To ensure smooth efficient cycling action, the tension belt braking system on your Exercise Cycle has been correctly adjusted by our factory during production.

To adjust the pedaling resistance during use, start by turning the Tension Control (19) fully ANTI-CLOCKWISE at the start of your workout. Gradually increase the pedaling resistance by turning the Tension Controller Knob CLOCKWISE as required.


LEVELLING THE BIKE

For security and stability, your bike has a factory welded frame and once fully assembled correctly, should not need further alignment. However, in the interest of safety, please always ensure that your Cycle is positioned on a solid, flat surface. If necessary, use a rubber mat underneath to reduce the possibility of slipping in use. If you need to make a fine adjustment, simply twist the end of either Rear Frame Stabilizer Adjustable Hex End Cap (27) to compensate for uneven floors.



HOW TO FOLD


Using the Locking Pin (3) to fold and unfold the Bike. When in use, the Locking Pin (3) is in position A. When folded, the Locking pin (3) is in position B.




HOW TO ADJUST

The Saddle Support has "Max" Sign to show the maximum height of Saddle.

You should not exceed this height. Unscrew the Seat Adjustment Knob (26) a couple of turns then pull the knob outwards to release the Seat Support Tube (6). Position the Seat Support Tube to the desired height allowing for a slight bend in the knee at the lowest pedal position and retighten the Seat Adjustment Knob (26).




SUGGESTED HEIGHT:



CONTROL PANEL OPERATION


FUNCTION

TIME	0:00 – 99:59 (min)
SPEED	0.0 – 999.9 (km/h)
DISTANCE	0.0 – 999.9 (km)
ODOMETER	0 – 9999 (km)
CALORIES	0.0 – 999.9 (Kcal)
PULSE	40 – 240 (BPM)

	<ol style="list-style-type: none"> 1. MONITOR 2. ODOMETER 3. CALORIES 4. PULSE 5. MODE 6. TIME 7. DISTANCE 8. SPEED 9. SCAN
--	--

FUNCTION DESCRIPTION

MODE	Select different function
SCAN	Changing from function to function every 4 seconds
TIME	Count up
SPEED	Cycle speed
DISTANCE	Exercise distance
CALORIES	Computed theoretical calorie burn
ODOMETER	Accumulated total distance
PULSE	Actual exercise pulse rate

	<p>Note:</p> <ol style="list-style-type: none"> 1. Compatible with iOS and Android system 2. Console and mobile device connection via Tunelinc, once connecting, the display will be off. 3. Stop training for 4 minutes, the main screen will be off. 4. If the computer displays abnormally, please re-install the battery and try again. 5. Battery Spec: 1.5V UM-3 or AA (4PCS).
---	--

POWER ON/OFF

Power on: LCD will display all segments with Beep sound as Drawing A.


Power off: Without any signal been transmitted into the monitor for 4 minutes, and the monitor enter to SLEEP.

OPERATION

1. When monitor power on (or press MODE, RESET key and hold for 3 seconds), LCD will display all segments with Beep sound for one second and enter to SCAN mode as Drawing A.
2. With any signal been transmitted into the monitor, the value of TMR, DST, and CAL will start to count up as Drawing C.
3. Without any signal been transmitted into the monitor for 4 minutes, the monitor will enter to SLEEP mode.




TROUBLE SHOOTING

- When the display shows Drawing D, it means the batteries need to be changed.
- If there is no signal when you pedal, please check if the cable is well connected.








iBIKING+ INSTRUCTIONS

To operate iBiking+, first you need to connect your 3c device and computer through 3.5mm cable. Then download iBiking+ from Google play or App store.

	<p>Note:</p> <p>Download iBiking+ in Google play, system requirements: 480*800, 720*1280, 1280*800 Android 2.2 or above.</p> <p>Support Android devices: Samsung Galaxy Note 1~4, Samsung Galaxy S2~5, HTC NEW ONE, HTC D316d, HTC M8, SONY Z ULTRA.</p>  <p>Download iBiking+ in APP STORE, system requirements: iOS 5.1.1 or above.</p> <p>Support iOS devices: iPhone4s, iPhone5, iPhone5s, iPhone6, iPhone6+.</p> 
---	---

STARTING iBIKING+


Step 1	Step 2	Step 3
		
<ul style="list-style-type: none"> • Entering the App • Press “Tunelinc” icon • Connection not success yet: 	<ul style="list-style-type: none"> • Press “Tunelinc” icon again to confirm 	<ul style="list-style-type: none"> • Successful connection: 

MAIN FUNCTION OF iBIKING+


The main functions of iBiking+ are: 1. training 2. gym center 3. setting 4. information

TRAINING

The main function of training are: 1. target 2. quick start 3. heart rate

1.  You can setting 3 target values, which are : 1. time 2. distance 3. calories

		
<p>*1 „X“ to clear *2 „Done“ to confirm</p>		


- After setting the target Values, it will start countdown during your workout.
2.  Quick start can present the values of time, distance, calories, speed, rpm, heart rate during exercise.



- After starting exercise user can press pause from console control to stop any time.
- When finish, the workout summary can post on Facebook, Twitter, Weibo.

3. You can setting 2 values: 1. heart rate 2.time


Main layout:



GYM CENTER

Combine with google map, setting and show the route when exercise.

1. Plan my own route



2. My favorite




There are five default routes in my favorites. User selected route can save in my favorites.

Main layout:



3. MapMyFitness

Combine with map my fitness.



Step 3



Press „MapMyFitness“

Step 4



Use the route database from MapMyFitness

SETTING

Log in by user's Google/ Facebook account or create a new account.



INFORMATION

All the workout histories show up.



Note:

1. Without receiving any reply comment of communications protocol, the APP would continue sending signal and wait for acknowledging. And over 15 seconds the Tunelinc would off line, and user needs to reset (such as: phone, message, or any sound disturbance comes in. In 15 seconds the connection would continue but if over 15 seconds, user

	<p>needs to reset.)</p> <ol style="list-style-type: none"> 2. Tunelinc's audio cable connector is 4 pin, and the length limit is 50cm. 3. Tunelinc's audio cable be sure to use the factory supplied to achieve high quality transmission. If using non-original audio cable, not only affect the transmit performance but also may happened unexpected result and we cannot provide assistance by then. 4. After insert the Tunelinc into audio jack do not rotate. The audio cable cannot be curl to prevent effect inductive action and avoid lead to poor contact of transmission. 5. As using Tunelinc do not put any device on charge in order to reduce the interference of the transmission. 6. Do not put the Tunelinc audio cable connector in humid environment. 7. Due to operate iBiking+ APP needs to increase the volume, therefore, if the device display the volume warning message, the user needs to press confirmation for beneficial APP subsequent operations.
--	--

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated hereunder determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 40/1964 Coll. Civil Code, Act No. 513/1991 Coll., Commercial Code, and Act No. 634/1992 Coll., Consumer Protection Act, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Borivojova Street 35/878, Prague 13000, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

"The Buyer who is the End Customer" or simply the "End Customer" is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

"The Buyer who is not the End Customer" is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions to the extent specified in the Commercial Code.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

The Warranty does not cover defects resulting from:

User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks

Improper maintenance

Mechanical damages

Regular use (e.g. wearing out of rubber and plastic parts, joints etc.)

Unavoidable event, natural disaster

Adjustments made by unqualified person

Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

**SEVEN SPORT s.r.o.**

Registered Office: Borivojova 35/878, 130 00 Praha 3, Czech Republic
Headquarters: Delnicka 957, 749 01 Vitkov, Czech Republic
Warranty & Service Centre: Cermenska 486, 749 01 Vitkov, Czech Republic
CRN: 26847264
VAT ID: CZ26847264
Phone: +420 556 300 970
E-mail: eshop@insportline.cz
reklamace@insportline.cz
servis@insportline.cz
Web: www.insportline.cz

SK**INSPORTLINE s.r.o.**

Headquarters, Warranty & Service centre: Elektricka 6471, 911 01 Trencin, Slovakia
CRN: 36311723
VAT ID: SK2020177082
Phone: +421(0)326 526 701
E-mail: objednavky@insportline.sk
reklamacie@insportline.sk
servis@insportline.sk
Web: www.insportline.sk

Date of Sale:

Stamp and Signature of Seller: