



USER MANUAL – EN
IN 13253 Triscooter WORKER Fliker 100



CONTENTS

IMPORTANT SAFETY NOTICE	3
SCOOTER PARTS AND COMPONENTS	4
ASSEMBLY INSTRUCTIONS	4
Step 1: Unfolding the scooter.....	5
Step 2: Handlebar assembly.....	6
Step 3: Adjusting height	6
Step 4: Folding the scooter	7
CHECK BEFORE RIDING.....	7
HOW TO RIDE	7
USER GUIDE AND MAINTENANCE	8
TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS.....	9

IMPORTANT SAFETY NOTICE

Please retain these instructions for future reference.

PRECAUTIONS: Like any other moving product, scooter riding can be a hazardous activity and it is possible to get into dangerous situations. Be sure to read the entire manual before riding. In particular, pay attention to the following notices.

This scooter is recommended for children aged 6 years to 10 years.

Maximum load for this scooter is 50 kg. According to EN 14619 standard.

Always wear proper protective equipment, such as an ANSI, GS, BS or ASTM approved helmet, elbow, kneepads, long sleeve shirt, gloves, long pants.

Please always wear and fasten your athletic shoes, and do not ride barefoot or in sandals.

Ride the scooter only on flat and level ground. **DO NOT** use the scooter on wet and uneven ground with rocks or gravel. In addition, **DO NOT** use the scooter at dusk or night or in wet or icy conditions.

DO NOT ride the scooter with only one hand but ensure that both hands are always holding the bars. You must hold the handlebars with two hands tightly.

DO NOT make a short or sharp turn when riding the scooter, and **DO NOT** lean your body on the handlebar when making a turn, as the handlebar of the scooter can be twisted, and the scooter may lose control.

DO NOT ride the scooter on slippery or wet ground, as the scooter with PU wheel can slip and lose control.

DO NOT ride the scooter on the slope of hill, especially **DO NOT** go down a hill in a long descending slope, as it can damage the unit or cause brake failure. Please be careful when passing such areas.

Press the brake lever on handlebar to ensure the brake is functioning. The brake bracket may be hot after continuous use, and **DO NOT** touch the brake bracket to prevent injury.

Turn the handlebar to left and right to make sure it works well and smoothly. Also check if the handlebar is fixed securely before riding the scooter.

All children and preteens should ride with adult supervision at all times. Supervisor shall inspect the scooter prior to use, making sure all parts are fully assembled and tightened to prevent accidents.

You must follow and obey the local traffic laws for a safe ride.

DO NOT use attachments not included with the scooter. **DO NOT** attempt to do any modifications by yourself.

Make sure all components are assembled and secured securely.

Injury may occur if the precautions above are not observed.

NOTE: Any photos of the scooter or decals in the owner's manual are intended to be as reference mainly, and there may be some difference from the unit you purchase.


SCOOTER PARTS AND COMPONENTS




PARTS LIST			
NO.	NAME	NO.	NAME
1	Hand Grip	7	Steering Tube
2	Handlebar	8	Brake Plate
3	Brake Lever	9	Front Wheel
4	Brake Cable	10	Folding Knob
5	Handlebar Clamp Cap	11	Action Deck
6	Adjustable Tube	12	Rear Wheel

ASSEMBLY INSTRUCTIONS

Open the box, and take out the scooter unit, wrench, stem cap for handlebar, bolts, and Velcro band from the box. Please check whether all parts and components are complete or not.




Step 1: Unfolding the scooter




Grasp the steering tube with one hand and raise it up to full unfolding. Screw in both of the knobs with the other hand, clockwise and tightly. Please make sure both of the dials are tightened securely. **(WARNING: Make sure your fingers are clear of the folding or pinch point.)**

Step 2: Handlebar assembly




Place the handlebar set onto in the center of the adjustable tube. (the brake lever shall be on the right hand side). Cover the handlebar with the clamp cap. Screw in the bolts, adjust for correct angle of the handlebar and ensure that it is central, and then tighten the bolts to complete the assembly. Make sure the handlebar cannot be moved forward or backward and is secured tightly.

Step 3: Adjusting height



This scooter can be adjusted to suit the height of different users. First release the quick release lever, pushing the spring bolt with one hand while the other hand pulls the adjustable tube up or pushes it down. Lock the spring bolt into one of the locking holes. Then tighten the quick release lever. Check that the adjustable tube cannot be moved.

Step 4: Folding the scooter




Tightly grasp the steering tube with one hand, meanwhile screw out one of the knobs, and then the other one. Push the handlebar down to reach the action decks. Wrap the scooter with the Velcro band and complete the folding. (**WARNING: Make sure your fingers are clear of the folding or pinch points.**)

CHECK BEFORE RIDING


1. First of all, please make sure the brakes are working correctly.
2. Secondly, please check whether the knobs are tightened and the handlebars are central & secured.
3. Thirdly, please check the rear wheels can be swung smoothly and the action decks are fixed well.
4. Finally, after checking the above points, you can start to ride the scooter.

HOW TO RIDE

1. Step on the action decks as shown in the picture below.



2. Swing your lower body to the left, and then swing to the right. Repeat these actions, and the scooter will move forward easily and continually.



USER GUIDE AND MAINTENANCE

1. Please rotate the bearings and wheels to see whether they work and do some adjustments or add lubricant if it's needed after the first 2 weeks of use.
2. The scooter can be folded and packaged with the Velcro band for easy carry. You can grasp the steering tube to carry the scooter.
3. It is not recommended to cover the painted metal tube with plastic bags or cloth. DO NOT use wet cloth to clean the painted body to prevent loss of gloss and peeling off. If the scooter body has lost gloss after one year of use, then a car wax can be applied to polish the painted parts.
4. Generally, it is suggested to disassemble and clean the scooter every 6 months and add lubricant on the moving parts. If any parts require replacing, please check with the dealer to make sure the parts specifications are correct.
5. The PU wheels are non-durable and may wear out after some time; please contact the seller to replace with new PU wheels for safe ride.
6. The wheels and wheel bearings may wear out, and you can change the wheels easily. Remove the center bolts with two wrenches and slide the wheel off its fork. Replace the wheel or wheel bearing, screw in the bolt through aligned fork and wheel, and then tighten the bolts with two wrenches on each side of bolts. Please ensure that you acquire the correct wheels or wheel bearings from local dealer.
7. If the brake cable is loose, please screw out the bolt and nut on the brake gear and pull the brake cable out with clamp. When the brake cable is pulled tensely, please screw in the bolt and nut on the brake gear at the same time. Then test the brakes to ensure that they are working correctly.
8. The self-locking nuts and other self-locking elements might lose their effectiveness, so please always make sure all components are assembled and secured before each use.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated here under determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Strakonická street 1151/2c, Prague 150 00, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints, wear of brake pads/blocks, chain, tires, cassette/multi wheel etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

CZ

SEVEN SPORT s.r.o.

Registered Office: Strakonická 1151/2c, Praha 5, 150 00, ČR
Headquarters: Dělnická 957, Vítkov, 749 01
Warranty & Service: Čermenská 486, Vítkov 749 01

CRN: 26847264
VAT ID: CZ26847264

Phone: +420 556 300 970
E-mail: eshop@insportline.cz
reklamace@insportline.cz
servis@insportline.cz

Web: www.inSPORTline.cz

SK

inSPORTline s.r.o.

Headquarters, warranty & service center: Električná 6471, Trenčín 911 01, SK

CRN: 36311723
VAT ID: SK2020177082

Phone: +421(0)326 526 701
E-mail: objednavky@insportline.sk
reklamacie@insportline.sk
servis@insportline.sk

Web: www.inSPORTline.sk