

USER MANUAL – EN
IN 13785 Children’s Roller Skates Action Toty



CONTENTS

PRODUCT DESCRIPTION 3
SAFETY PRECAUTIONS..... 3
MAINTENANCE 4
PRACTICAL INFORMATION 5
ROLLER SKATING TECHNIQUE 5
TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS..... 6

PRODUCT DESCRIPTION

Frame	Polypropylene
Brake	Heel brake
Boot inside	Comfortable inner lining - ComfortFit
Wheels	Front: 40x18 mm, Rear: 80x20 mm, Material: PU, Hardness: 82A
Bearings	ABEC5 Carbon
Max. user weight	60 kg (Class A – from 20 kg to 100 kg according to the standard EN 13899)

SAFETY PRECAUTIONS

- Read this manual carefully before first using and keep it for future reference.
- This product is suitable for sports and recreational using on a flat and solid surface. The best is a flat tarmac or concrete surface, quality pavement, quality wooden surface. Using it in a rough terrain (rough tarmac, sand or gravel) or overloading its capacity (jumping or going downstairs) could decrease its safety or speed up the wearing.
- Roller skates can go very quickly. We recommend not to overrate your skills. Use an approved helmet and protectors (elbow, knee, shoulder, wrist etc.). Wear reflective components to be well visible for other people in worsened visibility conditions.
- Children may use these skates only under supervision of an adult. Assembly must be done only by an adult.
- Don't violate local laws and regulations while skating. If you are not sure, ask local authorities for advice. Be familiar with all regulations and restrictions of using this product in the public sector.
- Use it only in a flat, clean and dry place which is away from traffic and pedestrians. Never use it on wet, oily or dusty surface.
- Use the heel brake to stop safely. Tilt your heel to the ground (the foot goes forward and the tiptoe up in the angle of 45°). Press the brake with your foot and keep your body straight. Never remove the brake to avoid the risk of fall and injury. The heel brake must be checked before each using and replaced with a new one if necessary.
- Regularly check all nuts, wheels, bearings and other components. They must be well tightened. Retighten, if necessary, using the right wrench.
- Quick-release and self-locking mechanisms can get loose in time. Check them regularly and re-tighten or replace if necessary.
- Wipe off dust and dirt with a dry cloth.
- Regularly check the wheels for wearing and replace them in necessary. Use only original spare wheels as specified.
- Never use damaged or worn product to avoid an injury. **Never exceed the max. weight limit of the user: 60 kg.**
- Never use the roller skates at temperature below 5 °C or on wet surface.
- Never use it at dusk, at night or in poor visibility.
- Frequent using may cause rapid wheel wearing and bearing releasing especially by low-cost roller skates. This is not an obstacle to further using. Wearing of these components is not warranty-covered.

- In the general way, aluminium chassis are noisier than PP chassis. The noisiness is directly proportional to the using frequency (worn wheels and bearings) and it is not a reason for complaint (warranty-claim). Also, wheels made of PVC and cheaper bearings (608Z, 608ZZ) are noisier while skating.


MAINTENANCE

1. Maintain it properly and regularly to increase its safety.
2. In case of any repairing, we recommend to contact the professional service.
3. Never use petroleum jelly or oil to lubricate the bearings. Use graphite or silicone lubricants.
4. Use only a cloth and soapy water to clean the boot inside. Let it dry at room temperature.
5. Never use organic solvents.
6. Remove immediately all sharp edges.
7. Respect the product distinction and particularity while maintaining it.
8. Damaged or worn wheels must be replaced only with wheels of the same type and marking. May be, some unusual noise occurs with time because of insufficient lubrication. Crease them again to assure proper function.
9. Adjust the size according to your foot. The roller skates must fit well.
10. After putting the roller skates on, do a few steps to make sure the screws and nuts are well tightened. If they are loose, stop using and retighten them immediately.
11. **Wheel replacing:** To replace the wheels, use an Allen key with the right size. Always use the same wheel size that has been used before. We recommend to use the PU wheels because of higher quality.
12. **Bearing replacing:** To replace the bearings, use the correct Allen key. Remove the wheels and pull out the bearings. Use original spare parts.
13. **Brake replacing:** Regularly check the brake for wearing. In a general way, if the angle between the frame and ground is bigger than 40° , the brake is worn over the limit. If the distance between the braking pad and ground is too big (>17 mm), the brake must be replaced immediately. Never skate with damaged or worn brake.
 - Use a wrench to screw off the bolt (1) and remove it.
 - Take the braking pad (2) out from the holder (3).
 - Put in a new braking pad and retighten the bold (1).
 - Make sure the fixture is solid and all bolts and nuts fit well.



PRACTICAL INFORMATION

- The size can be adjusted in four levels, as shown in pictures below, just by pushing a special button (Pic. B) and without having to use any tool. Push the button and pull the toe cap with your other hand. Choose the right size (A, B, C, D) and fix it in position by releasing the button.
- Pulling the right toe cap may cause braking or total stopping while skating. To brake and stop safely, install the brake so that it meets the ground.
- Never do any improper modification. You could reduce product safety.
- This product shall not be preset. The brake is on the right skate (Pic. C). To use it, slightly lift the right tiptoe so that the brake is in contact with the ground.



ROLLER SKATING TECHNIQUE

- Learn to skate and stop safely and properly before first using. If you are not sure, ask an experienced person for advice.
- Use the roller skates only in suitable places without any traffic or pedestrians, where there is no prohibition or restriction to do it.
- Bend your knees so that your toes are hidden under them while being looked from above to keep balance.
- In case of some fall stretch your hands forward to reduce the impact. Used protectors (wrist, knee and elbow) can protect you from being hurt. Pay attention and skate reasonably, because no protective component can provide the absolute protection.
- Take the skate posture. That means, keep your body to the ground as low as possible for better balance. Knees are bent and shoulders slightly forward. Keep your hands low and forward.

- To start moving, try to walk like a duck. Point your toes out and have your heels together, keeping the V-shape. Take a few steps until you will be familiar with this moving. Thereafter start gliding.
- Let your heels be directly under your body to exert pressure on the heel wheels.
- To go forward, push off from the heel area and don't press on your toes.
- **Heel Brake** – Slightly lift the toe-cap of the skate with a heel brake and push the brake onto the ground. Keep your knees bent and shift your weight slightly forward. To increase the braking intensity, bend the knees a bit more and shift your weight forward while increasing pressure on the braking skate.
- **T-brake** – If your roller skates are not equipped with a heel brake, we recommend to use the T-stop braking. This is however only suitable for advanced skaters with enough skating place to do it safely! Shift your total weight on one foot. Put your one foot behind the second one and create a right angle with it. At least shift your weight forward onto the inner wheel side of the rear skate and brake by increasing the pressure. This braking way can only be used, if the skater doesn't lean back on the rear skate and doesn't use it to keep balance.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated hereunder determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 40/1964 Coll. Civil Code, Act No. 513/1991 Coll., Commercial Code, and Act No. 634/1992 Coll., Consumer Protection Act, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Borivojova Street 35/878, Prague 13000, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

"The Buyer who is the End Customer" or simply the "End Customer" is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

"The Buyer who is not the End Customer" is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions to the extent specified in the Commercial Code.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages

- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.



SEVEN SPORT s.r.o.

Registered Office:	Borivojova 35/878, 130 00 Praha 3, Czech Republic
Headquarters:	Delnicka 957, 749 01 Vitkov, Czech Republic
Warranty & Service Centre:	Cermenska 486, 749 01 Vitkov, Czech Republic
CRN:	26847264
VAT ID:	CZ26847264
Phone:	+420 556 300 970
E-mail:	eshop@insportline.cz reklamace@insportline.cz servis@insportline.cz
Web:	www.insportline.cz

SK

INSPORTLINÉ s.r.o.

Headquarters, Warranty & Service centre: Elektrická 6471, 911 01 Trenčín, Slovakia

CRN: 36311723

VAT ID: SK2020177082

Phone:

+421(0)326 526 701

E-mail:

objednavky@insportline.sk

reklamacie@insportline.sk

servis@insportline.sk

Web:

www.insportline.sk

Date of Sale:

Stamp and Signature of Seller: