



**USER MANUAL – EN**  
**IN 14287 Windrunner inSPORTline Funcart**



## CONTENTS

SAFETY PRECAUTIONS.....	3
LIMITS .....	4
PARTS LIST .....	4
ASSEMBLY STEPS .....	4
SAFE USING .....	6
VELCRO STRAP PROTECTOR .....	7
MAINTENANCE AND CLEANING .....	8
TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS.....	8

## SAFETY PRECAUTIONS

- Read this manual carefully before riding and keep it for future reference.
- Check that all components, screws and nuts fit well. Check wheels and bearings for wearing. Replace them immediately, if necessary.
- Pay attention to speed limits and to correct braking.
- Don't endanger yourself or other people while riding. Don't ride on steep slopes or on uneven surface.
- Don't do any improper adjustment or maintenance. This could decrease safety of this device. Use it only according to this manual.
- Incorrect using can cause serious injuries (even lethal) or damage.
- Check this device regularly for damage or wearing. Worn parts must be replaced immediately.
- Never use any damaged device. Also don't use it if you find some sharp edges on this device.
- Acquire experience before first riding. Try to learn how to ride this device correctly before first using. If you are not sure, ask some other person for help or advice.
- Pay attention. Using this device on public roads or sidewalks (or in other places) is not allowed everywhere. Be sure that you don't violate local laws or prescriptions using this device. If you are not sure, ask local authorities.
- Don't use it on public roads (including motorways).
- Only one person can use it at the same time. Don't use it for transport of some other people.
- Never use it in darkness or at night. Don't use it in worsened visibility conditions or at dusk.
- Wear protectors (elbow, knee, wrist etc.) and helmet before each riding.
- This device is only for personal using. Don't use it for commercial purposes.
- Don't let children use this device.
- This device is not suitable for elderly and for pregnant women as well.
- Don't ride after drinking or using drugs. Don't carry items while riding.
- Be familiar with local traffic rules and comply with local laws. Have respect to pedestrians.
- Control your speed and pay attention to all facts, which could influence your riding. Good visibility is very important. Don't exceed the speed limit and observe the weight limit to avoid an accident.
- In case of any accident, stay in place and wait for help.
- When you ride along with other users, keep safe distance between each other to avoid a collision.
- Other activities (such as: phone using, listening to music etc.) can distract your attention from riding. Don't do it.
- Don't ride on slippery or wet roads and don't use it in rain. Don't ride on uneven surface. Don't use it in snow or in icy terrain. Avoid obstacles, dirts, small stones and steep slopes. Use this device only on flat and clean surface.
- Respect weight and speed limits while using this device.

## LIMITS

Respect these limits to use this product safely:

**Max. speed limit: 12 km/h**

**Max. weight limit: 100 kg**

## PARTS LIST

## ASSEMBLY STEPS

		
No.	Name	Quantity (Pc)
1	Seat	1
2	Handle	2
3	Frame	1
4	Front Pedal	1
5	Wheel	1
6	Anti-slip nut M8	4
7	45 mm Bolts	4
8	Screws	4
9	Knob	1
10	Rubber protector	2
11	Allen wrench 17	1
12	Allen wrench 13	1
13	Spanner	2


Follow these steps to assemble it correctly:

**Step 1:** Open the box and check that no part is missing.

**Step 2:** Connect the handle (2) to main frame (3) with 4X45 mm bolts (7) and 4XM8 nuts (6).

Please note that handles become wider at one end. The wider side should be away from the hover kart in order to give yourself more freedom to move.

Necessary tools: Allen wrench 17 (11) and Spanner (13)




**Step 3:** Connect the seat (1) to main frame (3) with 4 screws (8).

Necessary tools: Allen wrench 13 (12)



**Step 4:** Connect the front pedal (4) to main frame (3) with knob (9). To adjust it to your height, lift the knob (which has a spring system) slide the front pedal and place the knob into the most appropriate hole for your height.

Now that your frame is in one piece, place a rubber protector on each of the bars that hold together your hover kart. You will see that one side is longer than the other. This one goes on the inside to prevent your hover kart from getting scratched.



**Step 5:** Loosening the nut, adjusting the bars to fit your hover board and screwing the nut tight again.

The bars should match with your hover board.

Necessary tools: Spanner (13)



**Step 6:** Connect the frame to the hover board, turning your hover board into hover kart. First place hoverkart on top of your hover board, then fasten hoverkart with velcro strap. Please, make sure that the straps are properly secured before using the hover kart. You are finally ready to enjoy your hover kart to the max!



**WARNING:**

- Don't let this device work without any person sitting on. It could be dangerous.
- If you want to detach this device from the board, loose the straps.

## SAFE USING





**Before each riding:**

1. Sit on the seat.
2. Keep handles horizontally.
3. Turn on the power switch.





**Horizontal stop**

Keep both handles horizontal.

	<p><b>Backwards</b> Lift up both handles.</p>
	<p><b>Forward</b> Push both handles down.</p>
	<p><b>Turn left</b> Do not move your left handle. Put down the right handle.</p>
	<p><b>Turn right</b> Do not move your right handle. Put down the left handle.</p>

## VELCRO STRAP PROTECTOR

	<p>Pass the Velcro Strap through protector</p>
	<p>Fasten the Velcro Strap and make sure that the protector is facing down the ground.</p>

## MAINTENANCE AND CLEANING

Regular maintenance and cleaning can increase the lifespan of your device.

- Check all parts, wheels and bearings for wearing.
- Replace damaged or worn parts immediately.
- Don't use a lot of water to wash it. Metal parts could go rusty.
- Use only little soapy water (cold or lukewarm).
- Use a duster cloth to clean it.
- Don't use any chemical cleaners.

## TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

### General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated hereunder determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Borivojova Street 35/878, Prague 13000, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

"The Buyer who is the End Customer" or simply the "End Customer" is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

"The Buyer who is not the End Customer" is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

### Warranty Conditions

#### Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

#### The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person



- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

### **Warranty Claim Procedure**

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.



#### **SEVEN SPORT s.r.o.**

Registered Office:	Borivojova 35/878, 130 00 Praha 3, Czech Republic
Headquarters:	Delnicka 957, 749 01 Vitkov, Czech Republic
Warranty & Service Centre:	Cermenska 486, 749 01 Vitkov, Czech Republic
CRN:	26847264
VAT ID:	CZ26847264
Phone:	+420 556 300 970
E-mail:	eshop@insportline.cz reklamace@insportline.cz servis@insportline.cz
Web:	www.insportline.cz

---

#### **SK**

#### **INSPORTLIN s.r.o.**

Headquarters, Warranty & Service centre:	Elektricka 6471, 911 01 Trenčin, Slovakia
CRN:	36311723
VAT ID:	SK2020177082
Phone:	+421(0)326 526 701

E-mail:

objednavky@insportline.sk

reklamacie@insportline.sk

servis@insportline.sk

Web:

www.insportline.sk

Date of Sale:

Stamp and Signature of Seller: