



USER MANUAL – EN

IN 26364 Massage chair inSPORTline Fidardo



CONTENTS

SAFETY INSTRUCTIONS.....	3
PULL OUT THE FOOT REST	5
PRODUCT DESCRIPTION	6
FUNCTIONS.....	7
CONTROLLER	7
USE	8
BLUETOOTH SPEAKER.....	9
SWITCHING OFF THE CHAIR	9
CLEANING AND MAINTENANCE	9
TROUBLESHOOTING	10
VOICE CONTROL	10
SPECIFICATIONS.....	11
ENVIRONMENT PROTECTION	11
TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS.....	11

SevenSport s.r.o. reserves the right to make any changes and improvements to its product without prior notice. Visit our website www.insportline.eu where you will find the latest version of the manual

SAFETY INSTRUCTIONS

IMPORTANT SAFETY WARNINGS

- Place the product on flat and solid surface and keep at least 0.6 m free space around the product.
- Kids can move around this product only under adult supervision.
- Use only well-grounded socket and proper power cord.
- Pull out the plug after every use or during maintenance to avoid injury or damaging the product.
- Please use this product according to the manual.
- Do not use unauthorized modifications or accessories.
- Only for indoor use.
- Before first use, please read the manual carefully.
- Use this product as is described in the manual.
- Recommended maximum use time is 20 minutes.
- Do not use the device if it is damaged. (frame, leather etc.)
- Do not use the chair if the ventilation is blocked.
- Do not put on chair heavy items or objects with sharp edge.
- Do not fall asleep during massage for safety reasons.
- Do not use the chair after you consumed alcohol or other drugs or if you are sick or dizzy.
- Do not use within one hour after meal.
- Please be caution and do not use too strong massage.
- Weight limit: 150 kg
- For home use

POSITION OF MASSAGE CHAIR

- Do not use the chair in high temperatures or moist environments (e.g. bathroom).
- Do not use the chair immediately after temperature change.
- Do not use in dust or impropriety rooms.
- It is important to secure enough space and ventilation.

PEOPLE THAT SHOULD NOT USE THE PRODUCT

- People suffering from osteoporosis.
- People who have heart problems or are using electronic medical equipment (e.g. pacemaker).
- People suffering fever.
- Pregnant women.
- People suffering skin diseases.
- Kids younger 14 years old or people suffering mental illness can use this product only under adult supervision.

- People that are recommended rest from the doctor or people suffering from sickness.
- Do not use this chair if you have wet body.
- Do not use the heat function if you are heat sensitive.

SAFETY

- Maintenance should be done only by qualify person. Use should not disassemble the chair or do the maintenance by themselves.
- After every use unplug the cord.
- Do not use the product if the power cord, plug or socked are damaged.
- If you are not using the chair for long period of time, store it at a clean and dry place and secure the power cord.
- Do not expose the chair to high temperatures, direct sunlight and do not place the chair near heat source.
- If the power cord, plug or socked are damaged, ask professional or qualified person for help.
- For cleaning use wet sponge only. Do not use thinner, gasoline or alcohol for cleaning.
- Mechanical parts are assembled and made to require minimum maintenance.
- Pay extra attention to not damage the chair with sharp objects.
- Do not push the chair on uneven ground, always pick the chair up and then move.
- Do not let the chair to work for long periods of time.


COMMON PROBLEMS AND SOLUTIONS

- It is common that the motor is making sounds.
- If the chair is not working, please check the power cord, plug and socket and that the switch is ON.
- After the massage time is over the massage chair will turn OFF. The product will automatically shut down if it is overheated – wait at least half an hour before next massage.

Do not leave children unattended around the chair. Improper sitting or climbing on the chair can cause the chair to tip over or the child to fall




Before use, remove all items from your pockets (mainly keys, cell phone, etc.)



PULL OUT THE FOOT REST

Fold out the footrest (fig. 1).

Pull the footrest forward 5 cm (fig. 2).




PLACING

Make sure there is at least 30 cm of free space behind the chair.

Do not expose the chair to high temperatures and direct sunlight. We recommend using a mat or carpet under the chair.



VAROVÁNÍ



LIFTING THE CHAIR

Only place the chair on a solid floor with floor protection. Pay attention to the limbs and other parts of the body when lifting. Ask another person for help. Lift and place the chair carefully.


VAROVÁNÍ



MOVE THE CHAIR

Use the wheels to move. Tilt the chair to 45° as shown.

Make sure you switch off the chair and pull the plug from the power supply before moving it.

Make sure there are no obstacles, other people, or pets in the way.


Do not cross obstacles higher than 2 mm and wider than 5 mm.

Do not move the chair on wheels further than 50 m from the destination location.




REMOVING THE HEADREST AND BACK REST

For a greater change in the intensity of the massage, you can remove or attach the head and back rests (however, we recommend keeping the rests). The rests are attached with zippers.



PRODUCT DESCRIPTION



1. Headrest

2. Controller

3. Footrest

4. Loudspeakers

5. Back support


6. Buttock air massage

7. Arm rest cover

8. Arm rest

9. Side cover

FUNCTIONS



1. Charging port

2. Built-in microphone

3. Air massage of calves


4. 3D speakers on both guards

5. Neck massage

6. Waist warmer

7. Air massage of the buttocks

CONTROLLER



1. Display

2. Microphone

3. Heating

4. Power button

5. Adjusting the height of the massage head

6. Adjusting the width of the massage head

7. Adjusting the position of the massage

8. Speed of massage

9. Adjusting the height of the massage head

10. LED indicators

11. Automatic massage

12. Pressure massage

13. Type of massage

14. Lifting the backrest

15. Laying down the backrest

16. USB port

USE

Press the switch to start the chair, the chair will automatically recline, and the default program will start.

You will hear a sound signal (HH will be shown on the display), you can adjust the position of the massage heads in the shoulder area up and down using the buttons. If the position is not adjusted for 5 seconds, the massage will start.

The default message after startup is automatic message, but you can choose another one.

Automatic message

Name	Button	Function	Display
Automatic message		Comfortable message	A1
		Relaxation message: gentle and deep message for relaxation and anti-fatigue	A2
		Full body message: A deep message to revitalize the body's vitality	A3
		Neck and shoulder message: A unique neck and shoulder message against pain and fatigue	A4
		Back and waist message	A5
		Stretching: The footrest and back will rise and recline, stretching the legs and hips	A6

Manual message

Name	Button	Function	Display
Mode		Kneading: speed adjustment, indicator light	   
		Tapping: adjust speed and width, indicator light	   
		Kneading and tapping: Speed adjustment, indicator light	   
		Knocking: Adjusting speed and width, indicator light	   
		Shiatsu: Adjust speed and width, indicator flashes	   
		Kneading and knocking: Speed adjustment, indicator flashes	   
Intensity		3 intensity options	d1, d2, d3
Speed		3 speed options	P1, P2, P3

Adjusting the position of the massage

Name	Button	Function	Display
Massage position		Fixed position	H0
		Local massage	H1
		Upper body massage	H2
		Lower body massage	H3
		Full body massage	H5
Up button		The position of the massage heads (in a fixed position and during a local massage, you can use the buttons to adjust	Massage hand upside

Down button		the massage heads up and down)	Massage hand downside
-------------	---	--------------------------------	-----------------------

Heating

Name	Button	Function	Display
Heating		Turn on	LO
		Turn off	LF

Air massage

Name	Button	Function
Air massage	Air	Press to turn on/off or change the intensity of the massage

Adjusting the chair's incline

Name	Button	Function
Incline		Press and hold the button, the backrest will incline and the footrest will begin to lower. Release the stop button.
Recline		Press and hold the button, the backrest will start to recline and the footrest to rise. Release the stop button.

BLUETOOTH SPEAKER

Turn on Bluetooth on your smart device and search for a new device.

The chair is marked IMC-XXXX (X is the serial number). Pair your device.


SWITCHING OFF THE CHAIR

Press the power button on the controller. The massage turns off and all adjustable parts return to their original positions.


If the massage is turned off after the timer runs out, all adjustable parts will remain in the same position.

After turning off the chair via the remote control, turn off the chair at the main switch and disconnect from the power supply.

Turn off the main switch



Disconnect from the power supply



Unplug from the chair



CLEANING AND MAINTENANCE

- Do not use solvents.
- Use only products intended for leather treatment.
- You can clean the leather using a solution of 3% - 5% dissolved mild detergent (soap) in water. Clean the surface and then dry with a soft cloth.
- Do not use a hair dryer to dry.
- Some dyed fabrics can stain the leather.



TROUBLESHOOTING

Problem: Unable to move back and foot rest. A beep sounds when the button is pressed.

Solution: Due to the design of the chair, the chair has a limit of adjustment of parts. A beep will sound if you reach the limit.

Problem: The function does not start after starting the chair.

Solution: After starting the chair, it is necessary to select the program manually. If the chair is not in use for 20 minutes, it will automatically turn off. If you select the manual program and do not set all functions, these functions will be inactive.

Problem: The leather rubs against each other when adjusting the backrest positions.

Solution: Due to the materials used, friction is a common phenomenon. However, if you hear tearing noises, stop operation immediately and contact the service center.

Problem: The massage does not reach the shoulders or neck.

Solution: Adjust the position of the heads or adjust your seating position.

Problem: The power cord is hot or damaged.

Solution: Stop the use immediately and contact the service center.

VOICE CONTROL

No.	Command	Answer
1	Massage on	Ok, massage on
2	Massage close	Ok, massage close
3	Comfort massage	Ok, comfort massage
4	Relax massage	Ok, relax massage
5	Full body massage	Ok, full body massage
6	Neck and shoulder massage	Ok, neck and shoulder massage
7	Back and waist massage	Ok, back and waist massage
8	Stretch massage	Ok, stretch massage
9	Fixed massage	Ok, fixed massage
10	Change the other mode	Ok, change the other mode
11	Go little down	Ok, go little down
12	Go little up	Ok, go little up
13	Open the air pressure	Ok, Open the air pressure
14	Close the air pressure	Ok, Close the air pressure
15	Up the seat position	Ok, Up the seat position

16	Down the seat position	Ok, Down the seat position
17	Stop adjustment	Ok, stop adjustment

SPECIFICATIONS

Model	A1801-2
Name	Massage Chair
Voltage	110-120V ~ 60 Hz
	220 – 240V ~ 50 Hz/60 Hz
Power	90 W
Operating hours	20 min
Safety	Třída I

ENVIRONMENT PROTECTION

After the product lifespan expired or if the possible repairing is uneconomic, dispose it according to the local laws and environmentally friendly in the nearest scrapyard.

By proper disposal you will protect the environment and natural sources. Moreover, you can help protect human health. If you are not sure in correct disposing, ask local authorities to avoid law violation or sanctions.

Don't put the batteries among house waste but hand them in to the recycling place.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated here under determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Kutnohorská 531, Štěrboholy Retail Park, 109 00, Praha 10, ČR, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

Batteries

6-month battery warranty – we guarantee that battery's nominal capacity does not fall below 70% of its total capacity within 6 months of the product's sale.

The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints, wear of brake pads/blocks, chain, tires, cassette/multi wheel etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

CZ
SEVEN SPORT s.r.o.

Registered Office: Kutnohorská 531, Štěrboholy Retail Park,
109 00, Praha 10, ČR

Headquaters: Dělnická 957, Vítkov, 749 01
Warranty & Service: Čermenská 486, Vítkov 749 01

CRN: 26847264
VAT ID: CZ26847264

Phone: +420 556 300 970
E-mail: eshop@insportline.cz
reklamace@insportline.cz
servis@insportline.cz

Web: www.inSPORTline.cz

SK
Stores inSPORTline SK, s.r.o.

Headquaters, warranty & service center: Električná 6471,
Trenčín 911 01, SK

CRN: 46259317
VAT ID: SK2023299729

Phone: +421(0) 917 700 098
E-mail: objednavky@insportline.sk
reklamacie@insportline.sk
servis@insportline.sk

Web: www.inSPORTline.sk

About shipping

