

USER MANUAL - EN


IN 28045 Electric pump for paddleboards in SPORTline Puhalta (HT-737)

SevenSport s.r.o. reserves the right to make any changes and improvements to its product without prior notice. Visit our website www.insportline.eu where you will find the latest version of the manual.

SAFETY INSTRUCTIONS

- Please read the manual before use and keep it for future reference.
- Do not block any pump outlets.
- Protect against dirt, sources of heat, moisture and direct sunlight.
- Do not use if product is worn or damaged.
- Do not pull by the air hose.
- Do not use continuously for more than 20 min. After 20 minutes of continuous operation, it is necessary to let the pump cool down for at least 30 minutes.
- Never point the air hose at other people or animals.
- Do not leave unattended around children and animals.
- Do not leave running unattended.
- Keep away from water, rain, fire or direct sunlight.
- Before any maintenance or moving, make sure the pump is switched off.
- Check the set pressure before inflating.
- Do not use if explosive or flammable substances / gases are nearby.
- Do not use if the ambient temperature is higher than 40 °C.
- · Do not repair or modify the product yourself.
- Power supply: 12 V DC car cigarette lighter.

PRODUCT DESCRIPTION



USE - INFLATION


Connect the air hose to the inflation hole and tighten (Fig. 1).

Attach the correct air valve to the other end of the hose and screw it into the inflatable object (Fig. 2).

Plug into a power source.

Use the BAR or PSI buttons to select the required pressure unit. Use the + and – buttons to adjust the value from 0 to 20 PSI.

After setting the value, start inflation by pressing the power button. During operation, you can adjust the value using the + and - buttons. Press the power button repeatedly to turn off the inflator. Inflation automatically shuts off when the set value is reached.






USE - DEFLATION

Attach the air hose to the deflation hole. Tighten the hose correctly (Fig. 3). Attach the item you want to blow using the correct valve. Press the power button After blowing, press the power button again. Unplug from power.

In case the paddleboard attachment does not fit the valve on your paddleboard, try replacing the sealing ring (for example, a thicker one with a thinner one).



SPECIFICATIONS

Max. pressure	20 PSI	
Air flow	250(A) L/ min, 70(B) L/min	
Input voltage	DC 12V- 14.4V	
Performance	110 W	
Noise	≤85 dB	

PACKAGE CONTENTS







STORAGE AND MAINTENANCE

Unplug before any maintenance or storage.

Allow to cool before storing.

Store in a dry, shady and well-ventilated place.

ERROR MESSAGES

Unable to start	Badly connected	Make sure it is properly connected in 12V DC.
	Burned out fuse	Replace the fuse.
	Overheating or overload	Let the pump cool down
Low pressure	Check that the outlets are not blocked	Check for blocked outlets or air hose
	Badly connected air hose or valve	Check the wiring
E3	Air leakage	Check for air leaks
HIVE	Low voltage (less than 10.5 V)	Connect to proper power source
U-H	High voltage (more than 17 V)	Connect to proper power source
Overheating	Protection against overheating	Let the pump cool down
LO/HI E6	Overload protection	Check that the vents are not clogged with debris.
The set pressure is not reset	Restart the value	Hold the PSI button for 3 seconds

ENVIRONMENT PROTECTION

After the product lifespan expired or if the possible repairing is uneconomic, dispose it according to the local laws and environmentally friendly in the nearest scrapyard.

By proper disposal you will protect the environment and natural sources. Moreover, you can help protect human health. If you are not sure in correct disposing, ask local authorities to avoid law violation or sanctions.

Don't put the batteries among house waste but hand them in to the recycling place.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated here under determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Kutnohorská 531, Štěrboholy Retail Park, 109 00, Praha 10, ČR, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

"The Buyer who is the End Customer" or simply the "End Customer" is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

"The Buyer who is not the End Customer" is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

Batteries

6-month battery warranty – we guarantee that battery's nominal capacity does not fall below 70% of its total capacity within 6 months of the product's sale.

The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints, wear of brake pads/blocks, chain, tires, cassette/multi wheel etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

CZ SEVEN SPORT s.r.o.

Registered Office: Kutnohorská 531, Štěrboholy Retail Park,

109 00, Praha 10, ČR

Headquaters: Dělnická 957, Vítkov, 749 01 Warranty & Service: Čermenská 486, Vítkov 749 01

CRN: 26847264 VAT ID: CZ26847264

Phone: +420 556 300 970
E-mail: eshop@insportline.cz

reklamace@insportline.cz servis@insportline.cz

Web: www.inSPORTline.cz

About shipping



SK

Stores inSPORTline SK, s.r.o.

Headquaters, warranty & service center: Električná 6471, Trenčín 911 01, SK

CRN: 46259317 VAT ID: SK2023299729

Phone: +421(0) 917 700 098 E-mail: objednavky@insportline.sk

objednavky@insportline.sk reklamacie@insportline.sk servis@insportline.sk

servis@irisportiirie.sk

Web: www.inSPORTline.sk