




USER MANUAL – EN

IN 29671 Recumbent inSPORTline ZenSeat 100



CONTENTS

SAFETY INSTRUCTIONS.....	3
IMPORTANT NOTES	4
PARTS LIST	5
DRAWING	7
ASSEMBLY	9
MACHINE LEVELING AND ADJUSTMENT OF ADJUSTABLE PARTS	17
CONSOLE	20
BLUETOOTH APP	26
ADVANTAGES OF RECUMBITION.....	26
EXERCISING INSTRUCTIONS	26
MAINTENANCE	27
STORAGE	27
IMPORTANT NOTICE.....	27
ENVIRONMENT PROTECTION	28
TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS.....	28

SevenSport s.r.o. reserves the right to make any changes and improvements to its product without prior notice. Visit our website www.insportline.eu where you will find the latest version of the manual.

SAFETY INSTRUCTIONS

- Read the manual carefully before first use and keep it for future reference.
- To ensure the best safety of the exerciser, regularly check it on damages and worn parts.
- If you pass on this exerciser to another person or if you allow another person to use it, make sure that that person is familiar with the content and instructions in these instructions.
- Only one person should use the exerciser at a time.
- Before the first use and regularly make sure that all screws, bolts and other joints are properly tightened and firmly seated.
- Before you start your work-out, remove all sharp-edged objects around the exerciser.
- Only use the exercise for your work-out if it works flawlessly.
- Any broken, worn or defective part must immediately be replaced and/or the exerciser must no longer be used until it has been properly maintained and repaired.
- Parents and other supervisory persons should be aware of their responsibility, due to situations which may arise for which the exerciser has not been designed and which may occur due to children's natural play instinct and interest in experimenting.
- If you do allow children to use this exerciser, be sure to take into consideration and assess their mental and physical condition and development, and above all their temperament. Children should use the exerciser only under adult supervision and be instructed on the correct and proper use of the exerciser. The exerciser is not a toy.
- Make sure there is sufficient free space around the exerciser when you set it up.
- To avoid possible accidents, do not allow children to approach the exerciser without supervision, since they may use it in a way for which it is not intended due to their natural play instinct and interest in experimenting.
- Please note that an improper and excessive work-out may be harmful to your health.
- Please note that levers and other adjustment mechanisms are not projecting into the area of movement during the work-out.
- When setting up the exerciser, please make sure that the exerciser is standing in a stable way and that any possible unevenness of the floor is evened out.
- No adjustable part may protrude and limit user movement.
- Always wear appropriate clothing and shoes, which are suitable for your work-out on the exerciser. The clothes must be designed in a way so that they will not get caught in any part of the exerciser during the work-out due to their form (for example, length). Be sure to wear appropriate shoes which are suitable for the work-out, firmly support the feet and which are provided with a non-slip sole.
- Be sure to consult a physician before you start any exercise program. He may give you proper hints and advice with respect to the individual intensity of stress for you as well as to your work-out and sensible eating habits.
- Class – HC
- Max. weight limit: 120 kg

WARNING! A system for monitoring heart rate may not be accurate. Overloading during training may cause serious injury or death. If you feel any discomfort, immediately stop the exercise!

IMPORTANT NOTES


- Assemble the exerciser as per assembly instructions and be sure to only use the structural parts provided with the exerciser and designed for it. Prior to the assembly, make sure the contents of the delivery is complete by referring to the parts list of the assembly and operating instructions.
- Be sure to set up the exerciser in a dry and even place and always protect it from humidity. If you wish to protect the place particularly against pressure points, contamination, etc., it is recommended to put a suitable, non-slip mat under the exerciser.
- The general rule is that exercisers and training devices are no toys. Therefore, they must only be used by properly informed or instructed persons.
- Stop your work-out immediately in case of dizziness, nausea, chest pain or any other physical symptoms. In case of doubt, consult your physician immediately.
- Children, disabled and handicapped persons should use the exercise only under supervision and in the presence of another person who may give support and useful instructions.
- Be sure that your body parts and those of other persons are never close to any moving parts of the exerciser during its use.
- When adjusting the adjustable parts, make sure they are adjusted properly and note the marked, maximum adjusting position, for example of the saddle support, respectively.
- Do not work out immediately after meals!


PARTS LIST

No	Name	Qty	No	Name	Qty
1	Consoles	1	36	Main frame	1
2	Bolt M5×10×Ø10	4	37	Retaining ring D12	1
3	Handle post	1	38	Rolling pin	1
4	Bolt M8×20×20×S13×Ø13	11	39	Roller sleeve	1
5	Washer D8	22	40	Screw	1
6	Curved washer D8×Ø20	7	41	Adjustable handle	1
7	Front beam	1	42	M6×20×S5 screw	2
8	Bolt M8×42×15×S5	2	43	Curved washer D6×Ø16	2
9	Wheelbarrow	2	44	Saddle adjustment handle	1
10	Washer d8×Ø16×1.5	16	45	Spacer	2
11	Nylon nut M8×H7.5×S13	3	46	Saddle Slider	1
12	Bolt M8×73×20×H5	4	47	Sliding frame cover	2
13	Nut M8×H16×S13	6	48	Bolt M6×16×S5	2
14	Rear stabilizer	1	49	Washer D6×Ø12×1.2	7
15	Cap Ø60.5	4	50	Scutcheon	1
16	Adjustable foot	4	51	Screw ST3×6×Ø5.6	4
17	Bolt M6×20×S5	6	52	Spring	1
18	Spring washer D6	19	53	Bolt M6×40×S5	1
19	Washer D6×Ø12×1	6	54	Seat swivel handle	1
20	Left/right handle	2	55	Nut M6×H6×S10	5
21	Round cap	4	56	Bearing 6804	2
22	Screw ST3×16×Ø5.6	4	57	Seat frame	1
23	Lower left handle cover	6	58	Washer D8×Ø22×2	1
24	Upper left handle cover	1	59	Bolt M8×47×20×H5	2
25	Lower right handle cover	1	60	Bolt M6×45	4
26	Upper right handle cover	1	61	Backrest frame	1
27	Screw ST4.2×16×Ø8	10	62	End cap J50	2
28	Left/right handrail pillar	2	63	Handrail	1
29	Connecting post	2	64	Foam roller Ø30	2
30	Cable holder Ø12	2	65	End cap Ø32	2
31	Left/Right pedal	2	66	Mesh backrest	1
32	Left/right décor cover	2	67	Seat	1
33	Seat frame	1	68	Crank cover Ø25	2
34	Rear trim cover	1	69	Nut M10	2
35	M8×20×S5 screw	5	70	Bolt M5×10×Ø8	7
71	Left / right crank	2	103	Washer D6×Ø16×1.5	1


72	Screw ST4.2×19×Ø8	6	104	Bearing 6001-2RS	2
73	Left/right chain guard	2	105	Freewheel	1
74	Handle cover	2	106	Washer D12×Ø15.5×0.3	1
75	Connecting frame	2	107	Spring	1
76	Bushing	2	108	Freewheel holder	1
77	Frame with eye	2	109	Washer D12×Ø17×0.5	1
78	Washer D8×Ø32×2	2	110	Bolt M8×12	1
79	Bolt M8×16×S5	2	111	Sensor	1
80	End cap Ø38	4	112	Sensor	1
81	Bearing 6203	2	113	Screw ST4.2×8×Ø8	5
82	Retaining ring D40	2	114	Engine	1
83	Retaining ring D17	2	115	Resistance cable	1
84	Small crank	2	116	Power cord	1
85	Bolt M6×16×S10	6	117	Adapter	1
86	Washer D6×Ø20×1	2	118	Extension cable 1	1
87	Bolt M8×40×S6	2	119	Extension cable 2	1
88	Retaining ring D20	1	120	Left handle cable 1	1
89	Bearing 6004-ZZ	2	121	Left handle cable 2	1
90	Case Ø20.1×Ø26×0.3	1	122	Left handle cable 3	1
91	Washer D20×Ø26×0.3	1	123	Right handle cable 1	1
92	Round Magnet	1	124	Right handle cable 2	1
93	Belt Ø260	1	125	Right handle cable 3	1
94	Middle shaft	1	126	Adjustable sleeve	2
95	Belt 6PJ400	1	127	External adjustable sleeve	2
96	Matrix	2	128	Screw ST3×10×Ø6	4
97	Adjustable chain bolt	2	129	Left/right handle	2
98	U frame	2	130	Adjustable plate	1
99	Nut M6×H5×S10	2	131	Bolt M5×10×S4	2
100	Nut M10×1×H5×S17	2	132	Internal adjustable sleeve	2
101	Flywheel	1	133	Screw M6x42x10xS5	2
102	Bolt M6 ×10×S10	1	134	Washer d8xØ25x2	2
			And	Allen key S5	1
			B	Wrench S13-15	1
			C	Cross wrench S13-14-15	1

DRAWING






ASSEMBLY

	_____	#4 M8*20*S13 11x
	_____	#5 d8 15x
	_____	#6 d8*Φ 20*2*R30 7x
	_____	#10 d8*Φ16*1.5 10x
	_____	#12 M8*73*20*H5 4x
	_____	#13 M8*H16*S13 6x
	_____	#17 M6*20*S5 6x
	_____	#18 d6 12x
	_____	#19 d6*Φ12*1 6x
	_____	#42 M6*20*S5 2x
	_____	#43 d6*Φ16*1.5*R16 2x
	_____	#49 d6*Φ12*1.2 4x
	_____	#59 M8*47*20*H5 2x
	_____	#60 M6*45*20*S5 4x
	_____	#72 ST4.2*19*8 2x
	_____	#A S5 1x
	_____	#B S13-15 1x
	_____	#C S13-14-15 1x


Step 1

Attach the front and rear stabilizers.




Step 2

Connect the cables and attach the handle post.




Step 3

Fixing the covers to the post (29) with screws (72).



Step 4


Mounting handles and pedals.



Step 5


Fastening the backrest frame (61) to the base (57).

Attaching the handle (44) to the seat slider (46).




Step 6

Fastening of handles (63) and seat (67).




Step 7

Bracket (1) and backrest (66) mounted.



MACHINE LEVELING AND ADJUSTMENT OF ADJUSTABLE PARTS


Place the machine in the desired location. Sit on it for 20 seconds and then dismount. Level the machine using the adjustable feet until the machine is stably erect. Tighten the adjustable nuts.




Warning: pay attention to the maximum height of the adjustable feet. Do not remove them from the thread.

MOVE


- Disconnect from the power supply.
- Hold the handles on the back of the machine.
- Place the machine on the transport wheels on the front stabilizer.
- Move the machine carefully.
- Ask another person for help if necessary.




Pull the lever (44) upwards to lock in position.




Pull the lever (44) down to move the seat.




To rotate the seat, press the lever (54).



Use the sleeves to adjust the handles (127)



CONSOLE



Exercise data is displayed in two modes:

- In a cycle. During exercise, the displayed data in the cycle changes every 6 seconds: TIME – DISTANCE – SPEED – PULSE – CALORIE – WATT.
- Fixed display: Manually select the displayed data: TIME, SPEED, CALORIE, DISTANCE, PULSE by pressing Display-ALT

WATT / RPM / BMI display

Press ENTER to switch between the displayed WATT / RPM / BMI readings

Resistance Adjustment: 16 Levels

SPECIFICATION

TIME	0:00 ~ 99:59 (Min: SEC) / 99:00 – 0:00 (SEC: MIN)
SPEED	0.0 ~ 99.9 km/h
DISTANCE	0.00 ~ 99.9 km
CALORIES	0 ~ 999 kcal
PULSE	40 – 240 BPM
RPM	0~999 RPM
WATTS (power)	0 – 899 W

DESCRIPTION OF FUNCTIONS / PROGRAMS

MANUAL	PROGRAM 1: Manual resistance adjustment
RESET	PROGRAM 2~11: preset programs
FAT POINTS	PROGRAM 12: Body Fat % and BMI
WATT	PROGRAM 13: the program determines the resistance according to the set power
H.R.C	PROGRAM 14~17: Resistance is determined by heart rate: 65%, 75%, 85%, custom heart rate adjustment
USER	PROGRAM 18 ~ 21: program set by user
RECOVERY	Heart rate recovery
Bluetooth	Bluetooth and app connectivity
Bluetooth H.R.C	Heart rate measurement with a Bluetooth device


BUTTON DESCRIPTION

UP	Choosing the next program Scroll up button Increase resistance
DOWN	Choosing the previous program Scroll down button Decrease resistance
RESET	Return to PROGRAM 1 All values are reset except: U1-U4, WATT and PULSE
START	Press to start/stop the program
RECOVERY	Press to start the heart rate recovery program
ENTER	During exercise, press to change the displayed WATT or RPM During program setup, confirm the set value
Display-ALT	Press to select the function you want to display

UNITS

Height	Weight	Speed	RPM	Distance	Calorie	Power	Pulse
Cm	Kg	Km/h	Speed/min	Miles	Kcal	W	BPM

MANUAL PROGRAM (PROGRAM 1)		



Press START to start the program, press ENTER to enter the settings.

In the settings, press ENTER to select the value you want to edit, the selected value will be TIME, DISTANCE, CALORIE, AGE will flash.

Use the UP / DOWN buttons to edit the value, press ENTER to confirm and go to the next entry.


After setting all values, press START to start the program.

During exercise, press the UP/DOWN buttons to adjust the resistance.

If a time, distance or calorie countdown is set, when 0 is reached, the program will turn off and an audible signal will sound.

Press START/STOP to stop and turn off the program.

PRESET PROGRAMS (PROGRAM 2 – 11)



Press UP/DOWN to select a program.

Press START/STOP to start the program, press ENTER to enter the settings.

In the settings, press ENTER to select the value you want to edit, the selected value will be TIME, DISTANCE, CALORIE, AGE will flash.

Use the UP / DOWN buttons to edit the value, press ENTER to confirm and go to the next entry.


After setting all values, press START to start the program.

The resistance is automatically adjusted according to the selected program. You can also adjust the resistance using the UP/DOWN buttons.

If a time, distance or calorie countdown is set, when 0 is reached, the program will turn off and an audible signal will sound.

Press START/STOP to stop and turn off the program.

BODY FAT PROGRAM (PROGRAM 12)



Press ENTER to enter the program settings.

In the settings, you need to enter the values: gender – height – weight – age. The selected value will flash.

Use the UP/DOWN buttons to set the value, press ENTER to confirm and move to the next value.

Press START/STOP to start the test, grasp the sensors on the handles. The display shows the % body fat after 8 seconds.

Hold the sensors for the entire length of the test.

BMI

Gender/Age	Malnutrition	Healthy	Slightly overweight	Overweight	Obesity
Man / ≤ 30	< 14	14~20	20.1 ~ 25	25.1~35	> 35
Man / > 30	< 17	17~23	Select size 23.1 ~ 28	28.1 ~ 38	> 38
Woman / ≤ 30	< 17	17~24	24.1~30	30.1~40	> 40
Woman / > 30	< 20	20~27	27.1 ~ 33	33.1 ~ 43	> 43

% of body fat

Gender	Low	Medium	Mid-high	High
Man	< 13%	13% - 25.9%	26% - 30%	> 30%
Woman	< 23%	23% - 35.9%	36% - 40%	> 40%

B.M.R (metabolism)


Average number of calories burned to survive per day

1300±100 (20-40 years)

BODY TYPE

B1	B2	B3	B4	B5	B6	B7	B8	B9
Skinny	Thin	Slightly Thin	Slim	Healthy	Slightly	Overweight	Obese	Obesity

WATT PROGRAM (PROGRAM 13)



Press ENTER to enter the settings.

Press ENTER to select the setting value: TIME – DISTANCE – WATT. The selected value will flash.

To start the program, press START, the resistance will automatically adjust according to the set WATT value.


Press START/STOP to start the program.

If a distance or calorie countdown is set, the program will turn off when 0 is reached. A sound signal will sound to indicate that the program has ended.

Press START/STOP to turn off the running programme.

Note: the WATT value is calculated according to torque and revolutions per minute. The WATT maintains a constant value, so depending on the pedaling pace, the resistance increases or decreases.

H.R.C PROGRAM (PROGRAM 14-17)



Use the UP/DOWN buttons to select a program.


Press START/STOP to start the program, press ENTER to enter the settings.

In the settings, press ENTER to select and confirm the value settings. The selected value will flash: TIME – DISTANCE – CALORIE – AGE (programs 14 – 16) – T.H.R (program 17).

Press START to start the program. The resistance is automatically adjusted according to the set heart rate. If a countdown is set, the program will be switched off when 0 is reached. A sound signal will sound to indicate that the program has ended.

Press START/STOP to turn off the running programme.

USER PROGRAM (PROGRAM 18-21)



Use the UP/DOWN buttons to select a program (U1 – U4).

Press START/STOP to start the program, press ENTER to enter the settings.

Press ENTER to switch between the functions TIME – DISTANCE – CALORIE – AGE – resistance.

Use the UP/DOWN buttons to adjust the value. Press ENTER to confirm and move to the next value.


Press START/STOP to start the program.

The resistance can be adjusted automatically or using the UP/DOWN buttons.

If a countdown is set, the program will be switched off when 0 is reached. A sound signal will sound to indicate that the program has ended.

Press START/STOP to turn off the running programme.

RECOVERY PROGRAM



Measure your heart rate during training.

End the training session and press RECOVERY.

Grasp the sensors on the handles.

The countdown from 0:60 will be displayed, and once the countdown reaches 0:00, the result F1 (best) – F6 (worst) will be displayed.

BLUETOOTH CONNECTIVITY

Turn on Bluetooth on your smart device. Find your machine.

You can use the corresponding program buttons to control the program.

CHEST STRAP

The machine is compatible with a 5.3 kHz chest strap.

ERROR CODES

E1: The adjustment mechanism is not working properly.

E2: Heart rate is not detected during the BODY FAT programme.

1. The console is powered by a 9V/1A power supply.
2. If the console displays incorrect data or measures incorrectly, plug in and unplug the power.

BLUETOOTH APP



Bluetooth connectivity supports Zwift and Kinomap

Zwift

Download the Zwift app, register, and log in. Go to the settings page:



On the PAIRED DEVICES page, click RUN for the treadmill or RIDE for the bike/elliptical trainer.

Then choose POWER SOURCE. From the menu, select the Bluetooth code that's the same as the code listed on your device's console. Then click OK to pair.

NOTE: Zwift remembers devices used in a previous session and may attempt to pair with those devices if available. If you see paired devices that you don't want to use, you can simply deselect them and select the device you want to pair.

Kinomap

Download the Kinomap app, register and log in. Go to the settings page:



Select MORE in the lower right corner, click on EQUIPMENT MANAGER, select + in the upper right corner and select the equipment type:

for  treadmill,  elliptical trainer,  bicycle;

Then select the Bluetooth tag of your choice, e.g., Anyrun, etc.;

Choose Interactive, the app will start the search, choose the Bluetooth code, which is the same as on the console. Then select ADD NEW EQUIPMENT. A notification will appear that the pairing was successful.

ADVANTAGES OF RECUMBITION

Recumbents are an excellent choice when it comes to stabilizing the lumbar back of your back, as you sit back while training on exercise bike you bend forward. Recumbent therefore supports better body holding.

Recumbents are also more favorable to your joints. The bottom of the back is laid on a large, stable saddle, and your knees and ankles are protected from possible injury.

The fact that the saddle is larger is often the biggest difference compared to classical exercise bike. Just the comfort of sitting is the difference that everyone who experiences this type of exercise bike will feel.

Recumbent is also a good option for most people with neurological disorders. If your back or joints suffer from rheumatoid arthritis, recumbent may be the best solution for you because of the weight distribution of your body.

EXERCISING INSTRUCTIONS

A successful workout begins with warm-up exercises and ends with cool-down (relaxing) exercises. The warm-up exercises should make your body ready for the main workout. The cool-down phase should protect your muscles from injuries and cramps. Do warm-up and cool-down exercises as shown in the chart below.



Touching your toes

Slowly bend your back from hips. Keep your back and arms relaxed while stretching downwards to your toes. Do it as far as you are able and hold the position for 15 seconds. Bend your knees slightly.



Upper thigh

Lean against a wall with one hand. Reach down and behind you. Lift up your right or left foot to your buttock as high as possible. Keep for 30 seconds and repeat twice for each leg.



Hamstring stretched

Sit and outstretch your right leg. Rest the sole of your left foot against the inside of your right thigh. Stretch out your right arm along your right leg as far as you can. Hold for 15 seconds and relax. Repeat all with your left leg and left arm.



Inside upper thigh

Sit on the floor and place your feet together. Knees are pointed outwards. Pull your feet as close as possible to your groin. Press your knees carefully downwards. Keep this position for 30-40 seconds if possible.



Calves and Achilles tendon

Lean against a wall with your left leg in front of the right one and your arms forward. Stretch out your right leg and keep your left foot on the floor. Bend your left leg and lean forwards by moving your right hip in the direction of the wall. Hold for 30-40 seconds. Keep your leg stretched and repeat exercising with other leg.

MAINTENANCE

- Clean with a soft cloth and a non-aggressive cleaner.
- Do not use aggressive cleaning agents.
- Only wipe the electrical parts with a cloth. Avoid contact with water.

STORAGE

Keep the recumbent in a clean and dry environment. Make sure the power switch is turned off and the exercise bike is not plugged into the power socket.

IMPORTANT NOTICE

- This exercise bike comes with standard safety regulations and is only suitable for home use. Any other use is prohibited and may be dangerous to users. We are not responsible for any injury caused by improper and forbidden use of the machine.
- Consult your doctor before starting training on the exercise bike. Your doctor should evaluate whether you are physically fit to use the machine and how much effort you are able to undergo. Incorrect exercise or switching of the body can harm your health.
- Carefully read the following tips and exercises. If you experience pain, nausea, breathing, or other health problems during exercise, immediately stop the exercise. If the pain persists, contact your doctor immediately.
- This exercise bike is not suitable as a professional or medical purpose. It can also not be used for healing purposes.

- The heart rate monitor is not a medical device. It provides only approximate information about your average heart rate, and any suggested pulse rate is not medically binding. Accumulated data may not always be accurate regarding uncontrollable human and environmental factors.

ENVIRONMENT PROTECTION

After the product lifespan expired or if the possible repairing is uneconomic, dispose it according to the local laws and environmentally friendly in the nearest scrapyard.

By proper disposal you will protect the environment and natural sources. Moreover, you can help protect human health. If you are not sure in correct disposing, ask local authorities to avoid law violation or sanctions.

Don't put the batteries among house waste but hand them in to the recycling place.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated here under determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Kutnohorská 531, Štěrboholy Retail Park, 109 00, Prague 10, ČR, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations, it depends whether the Buyer is the End Customer or not.

"The Buyer who is the End Customer" or simply the "End Customer" is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

"The Buyer who is not the End Customer" is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

Batteries

6-month battery warranty – we guarantee that battery's nominal capacity does not fall below 70% of its total capacity within 6 months of the product's sale.

The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damage

- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints, wear of brake pads/blocks, chain, tires, cassette/multi wheel etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

CZSEVEN SPORT s.r.o.

Registered Office: Kutnohorská 531, Štěrboholy Retail Park,
109 00, Prague 10, Czech Republic
Headquarters: Dělnická 957, Vítkov, 749 01
Service: Čermenská 486, Vítkov 749 01

CRN: 26847264 VAT ID: CZ26847264

Phone: +420 556 300 970
Email: eshop@insportline.cz
reklamace@insportline.cz
servis@insportline.cz

Web: www.inSPORTline.cz

SK

Stores inSPORTline SK, s.r.o.

Headquarters, warranty & service center: Električná
6471, Trenčín 911 01, SK

CRN: 46259317 VAT ID: SK2023299729

Phone: +421(0) 917 700 098 E-mail:
objednavky@insportline.sk
reklamacie@insportline.sk
servis@insportline.sk

Web: www.inSPORTline.sk

About shipping

