



**USER MANUAL – EN**

**IN 328200120 Electric Scooter Devron Zerga EH-100**




# CONTENTS

- SAFETY INSTRUCTIONS..... 3
- DESCRIPTION ..... 4
- DISPLAY..... 4
- ASSEMBLY ..... 5
- CHARGING ..... 5
- HOW TO START ..... 5
- MAINTENANCE ..... 6
- FOLDING..... 7
- PARAMETERS..... 7
- TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS..... 8


## **SAFETY INSTRUCTIONS**

- Read the manual carefully.
- Avoid riding in the rain.
- You should be extra careful when riding in poor visibility, bad weather conditions or in the evening.
- When riding on uneven ground, you should ride slowly and pay extra attention.
- Do not accelerate when riding downhill.
- Do not accelerate when walking with the scooter.
- Avoid riding into obstacles.
- Do not hang heavy objects on the handlebars.
- Do not push yourself when accelerating.
- Do not ride on public road.
- It is forbidden to turn handles when riding at high speed.
- Do not ride into the water that is deeper than 2 cm.
- Only one person can use the scooter at the time.
- Do not step on the back fender.
- Do not touch the disk brakes.
- You need to hold the handlebar when riding.
- Do not ride on stairs or on to jump obstacles.
- Ride safely when riding in public area.
- The faster you are riding the longer braking distance you need.
- Ride slowly in unfamiliar terrain.
- Always teach other people about safety and riding the scooter.
- Always wear protection equipment (helm, knee and elbow protection) and suitable boots.
- Do not put battery to or near fire.

## DESCRIPTION

	1. Accelerator
	2. Control panel
	3. Brake
	4. Folding mechanism
	5. Wheel motor
	6. Charging port
	7. Buckle
	8. brake light
	9. Disk brakes
	10. Kickstand
	11. Footboard

## DISPLAY

	1. Riding speed
	2. Speed indicator: low speed max 15 km/h (green light) or high-speed max 20 km/h (red light)
	3. Battery indicator: 3 lights up – 100%-86%, 2 lights up – 85-71% battery remaining.
	4. Turn on by pressing the button. Turn off by pressing and holding the button for 2 seconds. Double press the button to switch between speed modes.

## ASSEMBLY

1. Secure the main tube. (Pic. 1)
2. Install the crossbar on main tube. (Pic. 2)
3. Use hex wrench to lock both screws. (Pic. 3)
4. After installation try to turn on the scooter. (Pic. 4)

Picture 1



Picture 2




Picture 3



Picture 4



## CHARGING



## HOW TO START

1. Turn on the scooter and check the power indicator.
2. Put one foot on the footboard and use the second leg to push the scooter.
3. After that push the accelerator and put the both foot on the footboard.

4. You can speed up or down by accelerator. You can break with brake lever.
5. Turn slowly and tilt slightly to the side you want to turn.

## MAINTENANCE

### Cleaning

- Use soft damp cloth to wipe the dirt. You can use small amount of toothpaste and brush to clean and then use cloth to wipe the dirt. Do not use gasoline, alcohol, corrosive or other violent detergents. Do not use water pressure. When cleaning the water secure all electronic parts.

### Storing

- Store scooter in dry and shady place and avoid long term exposure to sunlight, overheating or cold environment.


### Battery

- Use only authorized batteries.
- Do not touch the battery contacts and do not open the battery cover. Do not touch the battery contact with metal objects. It can cause damage or serious injuries.
- Use only original charger.
- Recharge the battery after every use to extend battery life.
- Do not expose the battery to temperatures higher than 50°C and lower than – 20°C.
- Do not put battery to or near fire.
- If you plan not to use the battery for longer than 30 days fully charge the battery and recharge the battery every 60 days.
- Do not fully discharge the battery. This can reduce the battery lifespan.
- In cold environment the effectiveness of battery is reduced.

### Brakes

- You can tighten or loosen the brakes by M5 hex wrench.
- If you want to loosen the brakes you need to loosen the brake cable and then tighten the plate screw again.
- If you want to tight the brake you need to pull the brake cable and then tighten the plate screw again.

Disk brake screw




### Wheels

You can inflate the tires. Remove the cap and inflate the tires and then put back the caps.

## FOLDING

Turn off the scooter. Release the folding mechanism and secure the main tube on the bucked on rear fender.



## PARAMETERS

The battery lifespan depends on many aspects such as user weight, temperature etc. Ideal conditions are: user weight 75 kg and 25°C degrees.

Dimension	length x width x height	1080 x 430 x 1140 mm
	Folded: length x width x height	1080 x 430 x 490 mm
Weight		12.5 kg
Requirements	Max. load	120 kg
	Age	From 16 years old
	Height	120-200 cm
Scooter parameters	Max. speed	20 km/h
	Range	18-25 km
	Climbing	15°
	Working temperature °C	from -10°C to 40°C
	Storage temperature °C	from -20°C to 45°C
	Protection levels	IP54
Battery parameters	Rated voltage	36V
	Max. charging voltage (VDC)	42V
	Rated capacity (Wh)	250
Motor parameters	Rated power (W)	250W
	Max power (W)	500W
Charger parameters	Rated power (W)	71W
	Rated input voltage (VAC)	110-210V
	Rated output voltage (VDC)	42V
	Rated current (A)	1.7V
	Charging time	about 3 hours

# TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

## General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated hereunder determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 40/1964 Coll. Civil Code, Act No. 513/1991 Coll., Commercial Code, and Act No. 634/1992 Coll., Consumer Protection Act, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Borivojova Street 35/878, Prague 13000, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions to the extent specified in the Commercial Code.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

## Warranty Conditions

### Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

### The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

## Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.



If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.



**SEVEN SPORT s.r.o.**

Registered Office:	Borivojova 35/878, 130 00 Praha 3, Czech Republic
Headquarters:	Delnicka 957, 749 01 Vitkov, Czech Republic
Warranty & Service Centre:	Cermenska 486, 749 01 Vitkov, Czech Republic
CRN:	26847264
VAT ID:	CZ26847264
Phone:	+420 556 300 970
E-mail:	eshop@insportline.cz reklamace@insportline.cz servis@insportline.cz
Web:	www.insportline.cz

---

**SK**

**INSPORTLIN s.r.o.**

Headquarters, Warranty & Service centre:	Elektricna 6471, 911 01 Trencin, Slovakia
CRN: 36311723	
VAT ID: SK2020177082	
Phone:	+421(0)326 526 701
E-mail:	objednavky@insportline.sk reklamacie@insportline.sk servis@insportline.sk
Web:	www.insportline.sk

Date of Sale:

Stamp and Signature of Seller: