



USER MANUAL – EN
IN 3370120 Three-Wheel Stroller/Tricycle with Tow Bar
Coccolle Evo



Picture is for illustration purposes only.

CONTENTS

SAFETY INSTRUCTIONS..... 3
MAINTENANCE 3
PARTS LIST 4
PRODUCT SPECIFICATION 5
ASSEMBLY STEPS 5
TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS..... 9

SAFETY INSTRUCTIONS

- Read this manual before first use and keep it for future reference.
- This product is intended for children in age from 9 to 72 months. Never exceed this limit.
- The max. weight limit is: 25 kg
- Use this product only according to the manual and only for intended purpose. Don't do any improper modification to avoid product damage or personal injury.
- Keep it away from fire.
- Only an adult person may assemble it.
- Don't use it as a toy and don't use it on roads or in traffic.
- During using, place feet of your child on the foot rests. You can protect them from injury by moving pedals.
- Use it reasonably and according to local laws and regulations.
- For higher safety use protective garments (helmet and protectors). Always wear shoes.
- Regularly check this product for damage or wearing. Never use damaged or worn product. All damaged parts must be replaced immediately. Regularly check all bolts and nuts. They should be properly tightened. Retighten, if necessary.
- This product meets following standards: EN 71-1, EN 71-2, EN 71-3


















MAINTENANCE

- After unpacking the package and protective material, store it in a specified place or dispose it according to local laws and environmentally friendly.
- Regularly check all screws, bolts and nuts before each use. Retighten, if necessary.
- Assemble it correctly and check it before each use to avoid an injury.
- Respect the weight limit and don't exceed it.
- Don't use it in wet conditions or in bad weather. Never use it at night, at dusk or in poor visibility.
- Avoid extreme temperatures as well.
- Avoid collision especially with hard object.
- Never use a damp cloth to wipe painted surface. You could scratch it.
- Use natural oils to prevent metal and welded parts from going rusty.
- Keep the package bag avoid from children because of suffocation hazard. Never let your child unattended.
- This product can be used in two ways: by a child while sitting and moving pedals, pushed by an adult (the child sits on the seat and has feet on the footrest).

WARNING:

- This product can be used only under adult supervision.
- Don't use it on public roads or in traffic.
- If the device is pushed by an adult person, the child must have feet on the footrests to avoid an injury.

PARTS LIST

		
A) Frame	B) Front wheel	C) Handlebar bar
		
D) Seat	E) Front fork	F) Seat cover and backrest
		
G) Middle footrest	H) Safety guard	I) Canopy
		
J1) Push-bar top J2) Push-bar bottom	K) Basket	L) Push-bar bag
		
M) Baby footrest	N) Rear wheels	O) Rear fork
		Tool
P) Fender	Q) Rear axle	



PRODUCT SPECIFICATION

Intended age	9-72 months
Max. load capacity	25 kg
Intended height	70-110 cm
N.W.	8.2 kg
Packing size	600x520x260 mm
Material	Metal, PP, ABS, TPR, Cloth

ASSEMBLY STEPS

STEP 1

- First take off the screws on the fender (P) and then insert the front fork (E) onto the fender. Use screws to tighten them. Remove screws on the front fork and insert the front fork into the front wheel (B). Finally tighten firmly all the screws.



STEP 2

- Remove screws on the rear fork (O) and insert the frame (A) into the rear fork. Tighten up the screws properly.



STEP 3

- Insert the front wheel into the frame (A).



STEP 4

- Insert the rear wheel (N) into the rear fork by the rear axle (Q). Make sure that the rear wheel is fixed.



STEP 5

- Take off the screw on the handlebar (C) and then insert the handlebar into the frame. Tighten them up with screw.



STEP 6

- Remove the screw on the middle of the frame (A) and then install the seat cover and the backrest (F) on the seat (D). Secure the seat, the safety belt and the frame using a screw.



STEP 7

- Insert the safety guard (H) onto the handlebar and on the seat.



STEP 8

- Insert the seat cover and the backrest (F) onto the safety guard. Then attach the safety belt to the seat and secure with a screw.



STEP 9

- Take off the screws on the push bar bottom (J2) and then insert the push bar top (J1) into the push bar bottom. Secure it with a screw. Remove the screw on the backside of the frame (A) and slide the complete push bar into the frame (A). Tighten it with a screw. Install the push-bar bag (L) onto the push bar.



STEP 10

- Slide the canopy (I) onto both sides of the backrest.



STEP 11

- Insert the footrest (M) under the frame and secure it with a screw. Then insert the middle footrest (G) into the frame and tighten up with screw.



STEP 12

- Complete the assembly as shown below.



TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated hereunder determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 40/1964 Coll. Civil Code, Act No. 513/1991 Coll., Commercial Code, and Act No. 634/1992 Coll., Consumer Protection Act, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Borivojova Street 35/878, Prague 13000, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions to the extent specified in the Commercial Code.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

The Warranty does not cover defects resulting from (if applicable):

- User’s fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages

- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.



SEVEN SPORT s.r.o.

Registered Office:	Borivojova 35/878, 130 00 Praha 3, Czech Republic
Headquarters:	Delnicka 957, 749 01 Vitkov, Czech Republic
Warranty & Service Centre:	Cermenska 486, 749 01 Vitkov, Czech Republic
CRN:	26847264
VAT ID:	CZ26847264
Phone:	+420 556 300 970
E-mail:	eshop@insportline.cz reklamace@insportline.cz servis@insportline.cz
Web:	www.insportline.cz

SK

INSPORTLINE s.r.o.

Headquarters, Warranty & Service centre: Elektricka 6471, 911 01 Trencin, Slovakia

CRN: 36311723

VAT ID: SK2020177082

Phone:

+421(0)326 526 701

E-mail:

objednavky@insportline.sk

reklamacie@insportline.sk

servis@insportline.sk

Web:

www.insportline.sk

Date of Sale:

Stamp and Signature of Seller: