



**USER MANUAL – EN**

**IN 449 Pedometer inSPORTline PedoBasic**



**CONTENTS**

FEATURES..... 3

BUTTON OPERATIONS ..... 3

    Time and step counter mode ..... 3

    Distance counter and stopwatch mode..... 4

    Calories burned and ODO (total distance counter) mode ..... 4

    Target calories and calories burned per day mode ..... 4

    Motion sensitivity slide switch ..... 4

HOW TO WEAR YOUR PEDOMETER..... 5

    Situations that may affect the accuracy of the step counter ..... 5

BATTERY REPLACEMENT ..... 5

MAINTENANCE ..... 5


TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS..... 5

## FEATURES

We introduce a series of highly accurate, reliable and effective digital pedometers for both walking and running. The features of the Pedometer model include a step counter, distance counter, calories burned counter, setting a target amount of calories burned, calories burned per day, time and stopwatch.

- Basic features:
  - Time and step counter mode
  - Distance counter and stopwatch mode
  - Calories burned and ODO (total distance counter) mode
  - Target calories and calories burned per day mode
- The step counter can count up to 99999 steps.
- The display can count up to 9999.9 kcal with 0.1 kcal resolution.
- Distance can be displayed up to 9999.9 km with 0.01 km resolution.
- The distance is displayed in km.
- Target calories consumption is displayed in a range from 1 to 9999.9 kcal.
- User weight and stride length can be set by user.
- The time can be displayed in 12-hour or 24-hour format. The display format is set by the user.
- The stop watch operates within the range of 59 minutes and 59.99 seconds.

## BUTTON OPERATIONS



### Time and step counter mode

- The stop counter is displayed in the upper part of the display while the time is in the lower part.
- Time setting: Press button 2 to enter setting mode. "12hr" will start flashing on the display.

- Press buttons 3 and 4 to choose between the 12-hour and 24-hour format. If you choose the 24-hour format, AM/PM will disappear. Press button 2 to confirm and move onto clock setting.
- Press buttons 3 and 4 to set the clock. Hold the buttons for fast scrolling. Press button 2 to confirm.
- Setting personal data: Press buttons 3 and 4 to set stride length and weight. Press button 2 to confirm.

### **Distance counter and stopwatch mode**

- Press the MODE key (1) to enter the distance counter and stopwatch mode.
- The distance is counted in the upper half of the display while the stop watch is displayed in the lower half.
- Press button 2 to start the stopwatch. Press button 2 to stop it. Press button 3 to reset the stopwatch back to zero.

### **Calories burned and ODO (total distance counter) mode**


- Press the MODE key (1) twice to enter the calories burned and ODO mode.
- Calories are shown in the upper half of the display while total distance travelled is shown in the lower half. Total distance travelled can only be reset by replacing the batteries.

### **Target calories and calories burned per day mode**

- Press the MODE key (1) three times to enter the mode.
- The target calories burned is shown in the upper part of the display while the calories burned during the day are shown in the lower half.
- There is a bar scale on the upper edge of the display that represents the percentage of target calories burned. Both calories burned per day and the bar scale will be reset each day.
- Press button 2 to set the target calories. The first digit on the left will start flashing. Set the value with buttons 3 and 4. Press button 2 to move on to the next digit. Press 2 again to confirm.
- The step counter cannot be reset. Only the calories counter can be reset and updated.

### **Motion sensitivity slide switch**

To adjust the unit's sensitivity to motion, use the motion sensitivity slide switch. To determine the proper motion sensitivity setting for an individual's walking pattern, experiment with different settings of the switch.



## HOW TO WEAR YOUR PEDOMETER


Your pedometer can be easily clipped to either side of the hip portion of your trousers or shorts. For best results keep the unit in line with the “crease line” of your trousers.

### Situations that may affect the accuracy of the step counter

- The step counter isn't perpendicular to the ground. The pedometer needs to be positioned at least 60 degrees perpendicular to the ground.
- Dragging feet in sandals or similar shoes or uneven footsteps in crowded areas
- Sports other than walking or jogging, walking up and down the stairs
- Travelling (bicycle, car, train, bus and other vehicles generate vibrations)
- Motion of standing or sitting

## BATTERY REPLACEMENT

- Release the battery compartment by unscrewing the screw.
- Use your fingernail to pull the battery out.
- Flip out the depleted battery and replace it by new CR2032 x 1 (3V) battery. Make sure the polarity is correct.
- Put the battery compartment back and fasten the screw.



## MAINTENANCE

- Avoid exposing the pedometer to extreme temperatures.
- To clean the step counter, use a dry soft cloth moistened in a solution of water and a mild neutral detergent. Never use volatile agents such as benzene, thinners, spray cleaners, etc.
- Store your pedometer in a dry place when you are not using it.
- Keep this manual and any other documentation that comes with the pedometer in a safe place for future reference.

## TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

### General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated hereunder determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 40/1964 Coll. Civil Code, Act No. 513/1991 Coll., Commercial Code, and Act No. 634/1992 Coll., Consumer Protection Act, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Borivojova Street 35/878, Prague 13000, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions to the extent specified in the Commercial Code.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

### **Warranty Conditions**

#### **Warranty Period**

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

#### **The Warranty does not cover defects resulting from (if applicable):**

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

### **Warranty Claim Procedure**

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the

damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.



**SEVEN SPORT s.r.o.**

Registered Office:	Borivojova 35/878, 130 00 Praha 3, Czech Republic
Headquarters:	Delnicka 957, 749 01 Vitkov, Czech Republic
Warranty & Service Centre:	Cermenska 486, 749 01 Vitkov, Czech Republic
CRN:	26847264
VAT ID:	CZ26847264
Phone:	+420 556 300 970
E-mail:	eshop@insportline.cz reklamace@insportline.cz servis@insportline.cz
Web:	www.insportline.cz

---

**SK**

**INSPORTLINÉ s.r.o.**

Headquarters, Warranty & Service centre:	Elektrická 6471, 911 01 Trenčín, Slovakia
CRN: 36311723	
VAT ID: SK2020177082	
Phone:	+421(0)326 526 701
E-mail:	objednavky@insportline.sk reklamacie@insportline.sk servis@insportline.sk
Web:	www.insportline.sk

Date of Sale:

Stamp and Signature of Seller: