



**USER MANUAL – EN**

**IN 6385 Trampoline with Handlebar inSPORTline Bambi  
Plus 97 cm**

**IN 6386 Trampoline with Handlebar inSPORTline Skippy  
Plus 122 cm**



# CONTENTS

SAFETY PRECAUTIONS..... 3  
HOW TO USE THE TRAMPOLINE..... 4  
LIST OF PARTS ..... 5  
ASSEMBLY ..... 5  
MAINTENANCE ..... 6  
TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS..... 7

## SAFETY PRECAUTIONS

Before using the trampoline for the first time, read this entire manual carefully. Following the safety precautions and instructions will help prevent possible injuries.

- **Maximum weight limit: 100 kg**
- **Unsuitable for children under 3 years of age.**

PARAMETERS	BAMBI	SKIPPY
Diameter	97 cm	122 cm
Weight	7,5 kg	8,5 kg
Height of the mat from the ground	23 cm	23 cm
Height of the handlebar from the ground	107,5 cm, 117,5 cm, 127,5 cm	110 – 140 cm
Handlebar width	87 cm	86 cm


- For home use only (both interior and exterior). The trampoline cannot be permanently affixed to the terrain.
- The trampoline must be assembled by an adult and with accordance to the assembly instructions. Inspect the trampoline before using it for the first time.
- ALWAYS CHECK YOUR TRAMPOLINE BEFORE USE, PAYING EXTRA ATTENTION TO ALL THE BOLTS, JUMP MAT AND THE POSITION OF ALL PADDING FEATURES (FRAME COVERS). DON'T USE THE TRAMPOLINE IF ANY PARTS ARE MISSING OR LOOK LIKE THEY SHOW WEAR AND TEAR. ALSO CHECK THE OVERALL STABILITY OF THE TRAMPOLINE. DO NOT USE THE TRAMPOLINE IF SOME PARTS ARE MISSING OR WORN.
- ALWAYS ENSURE THAT THE TRAMPOLINE IS USED ONLY BY ONE PERSON AT A TIME.
- DO NOT TRY TO TURN OR FLIP WHILE IN THE AIR.
- Children can use the trampoline only under adult supervision. Make sure that non-authorized people cannot access the trampoline.
- All trampoline users should be under adult supervision, regardless of their skills or age. The owner of the trampoline is responsible for ensuring the users are properly informed about the instructions in this manual.
- When using the trampoline, ensure that appropriate clothing is worn, preferably sportswear and socks. NEVER WEAR SHOES ON THE MAT. Before using the trampoline, make sure to empty your pockets of any sharp objects. Do not hold anything while jumping. Do not eat while jumping.
- Please be warned that trampoline is spring based and will allow the user to jump to a greater height than that on the ground. Please bear this in mind and wait until you are comfortable bouncing at low heights first.
- Always jump in the middle of the mat.
- Place the trampoline on an even surface.
- The trampoline shouldn't be placed on tarmac, concrete or any other hard surface. Nor should it be placed near other conflicting facilities (play grounds, swings, slides).
- It is recommended to use some sort of cushion mat in the area around the trampoline. Do not jump directly off the trampoline.

- Make sure there is at least 2 m of free space around the trampoline. Do not place it close to walls, fences, pools playgrounds, etc.
- Keep the area around the trampoline clean. Remove any possible obstacles. Do not place any objects onto the trampoline.
- Make sure there is adequate free space above the trampoline. The recommended minimal space is 7.3 m from the ground. Make sure there are no branches, electric cables and other hazards above the trampoline.
- Use the trampoline under proper lighting. Do not use the trampoline, if the mat is wet. Do not use the trampoline in strong wind.
- Do not use the trampoline if there are people or animals under it.
- Do not use the trampoline if you've consumed alcohol, drugs or coordination-affecting medication.
- Make sure you limit the time spent jumping (make regular breaks).
- No product can be completely risk-free and the safe use of the trampoline is always your responsibility.



## HOW TO USE THE TRAMPOLINE

- Be very careful when getting on and off the trampoline. **DO NOT** mount the trampoline by grabbing the frame pad, stepping onto the springs or by jumping onto the mat of the trampoline from an object (e.g. a deck, roof, or ladder). This is considered highly dangerous. **DO NOT** dismount by jumping off the trampoline and landing on the ground. If small children are playing on the trampoline, they may need help in mounting and dismounting.
- Do not climb onto the trampoline and its mat by:
  1. Grabbing the frame and stepping onto the spring/edge.
  2. Jumping directly off of the ground or another object.
- Never jump off directly onto the ground or a mat.
- Never jump onto or off the trampoline and never use the trampoline as a means to bounce onto or into another object.




- Initially, you should get accustomed to your trampoline and understand how much spring is in each bounce.

- The focus at this point should be your body position and technique until you can perform each jump with ease and control.
- Before you try to jump too high, the technique for stopping should be learnt as this will help prevent injuries should you feel you are jumping out of control.
- **AS THE USER LANDS ON THE BED KNEES SHOULD BE BENT SO THAT THEY STOP AND ABSORB THE SPRING IN THE MAT.** The position is shown in the image to the left. Arms are held out for increased level of balance.



- Keep your head straight and have the edge of the jumping area in sight.
- Always control the jump by taking off and landing in the middle of the trampoline. Do not jump onto the edge (especially the frame and the springs), it is not meant to support your weight.
- Do not perform somersaults of any type (backwards or forwards) on this trampoline. If you make a mistake when trying to perform a somersault, you could land on your head or neck. This will increase your chances of your neck or back being broken, which could result in death or paralysis.



- **NEVER TRY TO JUMP ONTO THE TRAMPOLINE SO THAT ANOTHER USER COULD BE PROPELLED HIGHER.**
- Do not jump for too long a time, until you're fatigued. You'll only increase the risk of an injury.

## LIST OF PARTS

- Trampoline
- Legs
- Handlebar

## ASSEMBLY

1. Check the inner threads in the leg supports (if they cannot be found on the visible side of the shaft, they are on the other side. Remove the rubber cap and place it on the other end of the support.)
2. Flip the frame upside down (A). There are 6/8 protrusions with rubber caps. Remove the caps.
3. Twist on then leg supports (C).
4. Flip the trampoline again so it stands on the leg supports. (D).
5. Make sure all legs are tightened correctly. Always inspect the leg supports before using the trampoline.

6. Affix the handlebar to the leg supports and join them together.



## MAINTENANCE

- If you want to ensure the trampoline's longevity, follow the above instructions.
- Regularly inspect the trampoline before each use for worn, damaged or missing parts.
  - Make sure all the spring connections (securing pins) are intact and cannot get loose during jumping.
  - Check the trampoline for sharp edges. Replace any damaged part you find.
  - Make sure the mat and the padding are not damaged.
  - Make sure the strap fasteners are secured tightly.
- In severe wind situations, the trampoline can be blown away. If you expect windy weather conditions, the trampoline should be moved to a sheltered area or disassembled.
- Any modifications made by the user (e.g. installing accessories) must be according to the instructions of the manufacturer.

- Over time, the durability of the trampoline parts is compromised by sunlight, rain, snow and extreme temperatures. During winter, the trampoline can be damaged by the fallen snow or freezing temperatures. It is recommended to store the mat inside.
- The trampoline is easier to move in two people. Lift up the trampoline slightly (do not drag it on the ground) and keep it horizontal. Tape the connections together so that the frame doesn't fall apart. If you want to move the trampoline considerably further, you should always disassemble it completely. CHECK THE ENTIRE TRAMPOLINE AFTER EVERY MOVE.

## **TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS**

### **General Conditions of Warranty and Definition of Terms**

All Warranty Conditions stated hereunder determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 40/1964 Coll. Civil Code, Act No. 513/1991 Coll., Commercial Code, and Act No. 634/1992 Coll., Consumer Protection Act, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Borivojova Street 35/878, Prague 13000, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions to the extent specified in the Commercial Code.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

### **Warranty Conditions**

#### **Warranty Period**

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

#### **The Warranty does not cover defects resulting from (if applicable):**

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

## Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.



### SEVEN SPORT s.r.o.

Registered Office:	Borivojova 35/878, 130 00 Praha 3, Czech Republic
Headquarters:	Delnicka 957, 749 01 Vitkov, Czech Republic
Warranty & Service Centre:	Cermenska 486, 749 01 Vitkov, Czech Republic
CRN:	26847264
VAT ID:	CZ26847264
Phone:	+420 556 300 970
E-mail:	eshop@insportline.cz reklamace@insportline.cz servis@insportline.cz
Web:	www.insportline.cz

---

## SK

### INSPORTLIN s.r.o.

Headquarters, Warranty & Service centre:	Elektricka 6471, 911 01 Trenčin, Slovakia
CRN:	36311723
VAT ID:	SK2020177082
Phone:	+421(0)326 526 701
E-mail:	objednavky@insportline.sk reklamacie@insportline.sk servis@insportline.sk



Web: [www.insportline.sk](http://www.insportline.sk)

Date of Sale:

Stamp and Signature of Seller: