



**DEVARON**

**Bateries**



**SPARE BATTERY FOR E-BIKES  
USER MANUAL**

[www.inSPORTline.cz](http://www.inSPORTline.cz)  
[www.inSPORTline.sk](http://www.inSPORTline.sk)

 **insportline**

# BATTERY

## WARNING

### Information about charger:



For indoor use only.



Do not dispose of the charger with common waste, it belongs to special containers.



Risk of electric shock - do not disassemble the charger



Double insulation

### Information about battery:



Do not throw into fire



Do not expose the battery to temperatures above 50 ° C



Do not expose the battery to excessive moisture or water.



Do not dispose of the battery with common waste, it belongs to special containers.



Avoid completely discharging the battery (so that it is empty) - it may be damaged, and the warranty cannot be claimed.

To prolong life, allow the battery to charge for 2 hours after each ride or after 3 months of inactivity.

## HOW TO REMOVE THE BATTERY

### Batteries placed on carriers:

Insert the key in the lock and turn the key 180 ° to the left to unlock the battery. Carefully slide the battery out of the carrier.



Fig. 1



Fig. 2

### Batteries placed on seat post:

Insert the key in the lock and turn the key 180 ° to the left to unlock the battery. Tilt the seat using the locking lever located under the seat. Grasp the battery by the handle and carefully pull it out of the bike frame.



Fig. 1



Fig. 2



Fig. 3


## BATTERY CHARGING

The e-bike motor is powered by a Li-Ion battery. Unlike other types of batteries, Lithium-Ion batteries are not subject to the so-called memory effect and can be charged even if they are not completely discharged.

The maximum battery capacity is usually reached after several charging cycles.

The first time you charge the battery, charging time should be approximately 12 hours.

- Connect the charger to the battery. The charging cable slot is located on the right side of the battery and is protected by a rubber cap on some models.



- Immediately after connecting the charger, the battery starts charging. During charging, the LED indicator on the charger will light up red, the battery is charging. When the battery is charged, the LED indicator lights up green.




If the LED does not turn red, it may be due to the battery overheating. In this case, allow the battery to cool before connecting the charger.

The battery is equipped with a charge progress indicator. After pressing the red (POWER) button, you can check the current charging progress.

5 LED = battery is charged to 100% of its capacity

3 LED = charging is 70-40% complete.

1 LED = charging is 0-40% complete.



If no LED lights up, it means that the battery is completely discharged and needs to be charged before use.

## **IMPORTANT INFORMATION**

- There is a risk of a short circuit when connecting the positive and negative poles of the battery.
- The battery is equipped with moisture protection and can be used in light rain. However, you should avoid direct contact with water.
- As electricity is so-called clean energy, riding an e-bike has no negative impact on the environment.
- Battery life increases at lower ambient temperatures.
- By default, battery lifespan is around 1000 charge cycles. With time and frequent use, the battery gradually loses its capacity and after a certain time it may lose its capacity completely.
- Do not expose the battery to high temperatures (above 50° C). Protect it from direct sunlight and do not place it near heat sources.
- Do not attempt to disassemble the battery. Contact your dealer if any problem occurs.
- Store the battery in a shady, cool, dry place.
- Use only the original charger supplied to charge the battery.
- Normal temperature is considered to be 25 ° C. In general, exceeding this temperature by 1 ° C will reduce battery life by 1%.

## **SAFETY INSTRUCTIONS**

- Read the manual and follow the instructions.
- Use only original charger to recharge the battery.
- Use only original battery to power up the bike.
- Improper use of the e-bike can endanger the safety of yourself and others. The seller accepts no liability for any damage to health or property caused by incorrect use of the product.
- Protect the charger, battery and electronic parts from dirt and water.

## **ENVIRONMENT PROTECTION**

After the product lifespan expired or if the possible repairing is uneconomic, dispose it according to the local laws and environmentally friendly in the nearest scrapyard.

By proper disposal you will protect the environment and natural sources. Moreover, you can help protect human health. If you are not sure in correct disposing, ask local authorities to avoid law violation or sanctions.

Don't put the batteries among house waste but hand them in to the recycling place.

## **TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS**

### **General Conditions of Warranty and Definition of Terms**

All Warranty Conditions stated here under determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Strakonická street 1151/2c, Prague 150 00, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

### **Warranty Conditions**

#### **Warranty Period**

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

#### **Batteries**

6-month battery warranty – we guarantee that battery's nominal capacity does not fall below 70% of its total capacity within 6 months of the product's sale.

#### **The Warranty does not cover defects resulting from (if applicable):**

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints, wear of brake pads/blocks, chain, tires, cassette/multi wheel etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

### **Warranty Claim Procedure**

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right

to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

**CZ**  
**SEVEN SPORT s.r.o.**

Registered Office: Strakonická 1151/2c, Praha 5, 150 00, ČR  
Headquarters: Dělnická 957, Vítkov, 749 01  
Warranty & Service: Čermenská 486, Vítkov 749 01

CRN: 26847264  
VAT ID: CZ26847264

Phone: +420 556 300 970  
E-mail: eshop@insportline.cz  
reklamace@insportline.cz  
servis@insportline.cz

Web: www.inSPORTline.cz

**SK**  
**inSPORTline s.r.o.**

Headquarters, warranty & service center: Električná 6471, Trenčín 911 01, SK

CRN: 36311723  
VAT ID: SK2020177082

Phone: +421(0)326 526 701  
E-mail: objednavky@insportline.sk  
reklamacie@insportline.sk  
servis@insportline.sk

Web: www.inSPORTline.sk