


IN GR7184 Freestyle Scooter Ethic Erawan Black

PRODUCT DESCRIPTION




SAFETY INSTRUCTIONS

- Always wear helmet and personal protective equipment e.g., elbow, knee, and wrist protectors. Helmet must be secured!
- Always wear sturdy closed shoes
- Ride on a smooth and paved surface, out of the reach of motor vehicles.

- Avoid sharp bumps, channels, ditches and sudden changes in the surface, the scooter can suddenly stop on the spot.
- Avoid surfaces with deposits of sand, gravel, clay, leaves and other dirt.
- Under all circumstances, avoid water or using the scooter in rain. Rain affects traction, braking and visibility. Do not use the scooter in the dark or during poor visibility.
- Avoid steep hills, descents and excessive speeds associated with descending hills.
- The brake heats up with intensive use. Do not touch the brake immediately after use.
- Follow the rules of local public roads. Pay attention to other participants and pedestrians.
- Do not use the scooter if it shows signs of damage. Replace worn or broken parts immediately.
- Before each ride, check the technical condition of the scooter. Tighten all screws, axles, head assembly, compression system, etc. There must be no clearance on the scooter.
- Children should only ride under the constant supervision of an adult.
- The scooter is designed for one user only.
- Do not overestimate your skills and use common sense while riding. Beginners should get acquainted with the behaviour of a scooter on a flat and empty space and learn the basics riding a scooter (starting, turning, braking, jumping).

ASSEMBLY

Adult assistance is required during assembly. The scooter is already pre-assembled. The final assembly consists in attaching the handlebars to the fork and thus creating the final unit.



Assembly of a scooter with a threaded fork

- 1) Loosen the screws on the sleeve that is threaded on the handlebars.
- 2) Place the handlebars, including the sleeve, on the fork as low as possible.
- 3) Align the handlebars so that the front wheel is straight in the direction of travel.
- 4) After aligning the wheel, tighten the screws on the sleeve. It is important to tighten the screws gradually.
- 5) Only when you are sure that all the screws are tightened you can use the scooter.

Scooter assembly with ICS compression system (thread is installed inside the handlebars)

- 1) Remove the front wheel (if it is not already removed).
- 2) Loosen the screws on the sleeve that is threaded on the handlebars.

- 3) Place the handlebars, including the sleeve, on the fork as low as possible.
- 4) Using a long Allen key, insert the enclosed screw into the fork and screw it into installed thread in the handlebars. Use this screw to adjust the rotational rigidity of the handlebars.
- 5) Align the handlebars so that the front wheel is straight in the direction of travel.
- 6) After aligning the wheel, tighten the screws on the sleeve. It is important to tighten the screws gradually.
- 7) Only when you are sure that all the screws are tightened you can use the scooter.

Assembly of a scooter with a HIC compression system (shim attached to the fork with a washer and short screw) and scooters with IHC (same as HIC, only with smaller outer diameter)

- 1) Loosen the screws on the sleeve that is threaded on the handlebars.
- 2) Put the handlebars, including the sleeve, over the shim, which is strung on the fork as low as possible.
- 3) Align the handlebars so that the front wheel is straight in the direction of travel.
- 4) After aligning the wheel, tighten the screws on the sleeve. It is important to tighten the screws gradually.
- 5) Only when you are sure that all the screws are tightened you can use the scooter.

Assembly of a scooter with SCS compression system ("Sleeve", which is thanks to the internal partition with washer attached to the fork)

- 1) Loosen the screws on the SCS that is attached to the fork.
- 2) Insert the handlebars into the SCS as low as possible.
- 3) Align the handlebars so that the front wheel is straight in the direction of travel.
- 4) After aligning the wheel, tighten the screws on the SCS. It is important to tighten the screws gradually.
- 5) Only when you are sure that all the screws are tightened you can use the scooter.

The wheels of the brand-new scooter, when taken out of the box, do not have to rotate smoothly. The bearings must first run in and then will rotate smoothly under load.

MAINTENANCE

- Observe the following rules for proper operation and longevity:
- Always store the scooter in a dry place.
- Clean the scooter after each use with a soft damp cloth. Do not use detergents or other agents for cleaning.
- If the scooter gets wet, dry all metal parts. This will prevent corrosion.
- The bearings in the wheel are encapsulated and do not require lubrication. Nevertheless, it needs occasional cleaning with a soft damp cloth. This will remove dust and possible chips.
- The wheels should be replaced if they are worn or broken. The lifespan of the wheels can be extended by swapping the front and rear wheels and also using the brake correctly. By using the brake correctly, you will avoid creating flats on the rubber of the rear wheel. Do not * depress * the brake and skid the rear wheel.



ADDITIONAL WARNINGS

- The scooter is not immune to damage. Individual parts are subject to wear.
- Please note that the statutory warranty period (period for exercising rights from defective goods) cannot be confused with the lifetime of the goods, ie the time during which, when used correctly, and With proper care, including maintenance, the goods can due to their properties, given purpose and differences in the intensity of its use. Lifetime of goods destined for extreme sports is prone to wear and tear caused by normal use.
- Scooters are tested according to the latest EN 14619 guidelines.

ENVIRONMENT PROTECTION

After the product lifespan expired or if the possible repairing is uneconomic, dispose it according to the local laws and environmentally friendly in the nearest scrapyard.

By proper disposal you will protect the environment and natural sources. Moreover, you can help protect human health. If you are not sure in correct disposing, ask local authorities to avoid law violation or sanctions.

Don't put the batteries among house waste but hand them in to the recycling place.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated here under determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Strakonická street 1151/2c, Prague 150 00, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

"The Buyer who is the End Customer" or simply the "End Customer" is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

"The Buyer who is not the End Customer" is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints, wear of brake pads/blocks, chain, tires, cassette/multi wheel etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

Registered Office: Strakonická 1151/2c, Praha 5, 150 00, ČR
Headquarters: Dělnická 957, Vítkov, 749 01
Warranty & Service: Čermenská 486, Vítkov 749 01

CRN: 26847264
VAT ID: CZ26847264

Phone: +420 556 300 970
E-mail: eshop@insportline.cz
reklamace@insportline.cz
servis@insportline.cz

Web: www.inSPORTline.cz

SK
inSPORTline s.r.o.

Headquarters, warranty & service center: Električná 6471, Trenčín 911 01, SK

CRN: 36311723
VAT ID: SK2020177082

Phone: +421(0)326 526 701
E-mail: objednavky@insportline.sk
reklamacie@insportline.sk
servis@insportline.sk

Web: www.inSPORTline.sk