




USER MANUAL – EN

SV16300 Kick Scooter Galaxy Calypso

SV16304 Kick Scooter Galaxy Zenit



ASSEMBLY

Check that all parts are present:

(1 pcs) main scooter frame with front fork.

(2 pcs) braking mechanisms (may vary depending on type).

(2 pcs) inflating wheels (may vary depending on type: 2x12" or 1x16" and 1x 12").

(1 pcs) handlebars including stem (see. Picture 1).

Entrust the assembly to specialized service.

Loosen the nuts on the front wheel hubs. If necessary, adjust the bearings on the axles so that the wheels rotate freely (i.e., the wheels cannot be stiff or too loose). Insert the wheel into the front fork of the scooter and tighten the nuts.

Attaching the handlebars: turn the stem down (if it is up, adjust the rotation and tighten evenly the 4 stem bolts (see. Picture 2).

If the stem is not connected and is placed separately, connect it to the handlebars and then tighten evenly the 4 stem bolts (see. Picture 2).

Insert the stem with the handlebars into the head tube of the scooter frame. Observe the minimum insertion depth. Align the stem with the handlebars so that the longitudinal axis of the handlebars is perpendicular to the axis of travel. Then tighten the handlebars with the Allen bolt in the stem (see. Picture 4). For the correct geometry, a slight bend of the front fork must point forward.

If a brake is included, insert the oval end of the brake cable into a larger round hole (different types of levers may have different attachments) located on the brake lever and insert the brake cable into the socket on the bottom of the handlebars (see. Picture 3).

Press both V-brake arms towards the wheel rim and use the appropriate wrench to adjust the brake blocks so that when breaking the blocks rub their entire braking surface against the side of the rim (see. Picture 7) if necessary, tighten or loosen the brake cable with the clamping screw (see. Picture 5) or adjusting screw on the brake lever so that there is a gap of approx. 1-2 mm between the rim and the brake block (see. Picture 6). If the wheel does not turn freely and "brakes" on one side, this can be adjusted by tightening the tensioning screw on the V-brake arm, which "brakes" the wheel (see. Picture 5), or by loosening the tensioning screw on the V-brake arm, which is further from the rim so that the wheel rotates freely. Always check the function of the brake before riding. If the brake lever (on the handlebars) contains an adjusting screw (located on the side of the lever), it can be shortened to shorten the distance between the lever and the handle (according to the size of the hand).

If the stand is not attached, screw it to the frame at the bottom so that the stand tilts to the left from the rider's point of view (see. Picture 1).

Inflate the tires according to the rider's weight, but not more than the value marked on the tires (bar / psi). If you are unfamiliar with the assembly steps, entrust the product to a professional service or contact your dealer.

RIDING INSTRUCTIONS

Always keep both hands on the handlebars when riding. While bouncing with one foot, stand on the footboard of the scooter with the other foot. Rotate the bounce leg regularly. To brake, press the brake levers on the handlebars. Brake with the rear brake, which is usually controlled by the right lever. Use the front brake only when braking or in an emergency.

WARNING: Sudden braking can cause a fall.

SAFETY INSTRUCTIONS

Read the manual carefully before assembly and use. Scooter Calypso has a maximum load capacity of 90 kg. Zenit scooter has a maximum load capacity of 100 kg. Tighten all bolts and nuts before use. For safe riding always wear a helmet, knee, elbow, and wrist protectors and sturdy shoes. Scooter is not designed for riding on public roads or traffic and riding in the dark or dusk. Do not use the scooters in the rain, on wet or slippery surface, gravel, and snow. Check bolts connections, tightening mechanisms and brakes regularly to prevent accident while riding. Do not brake too hard and suddenly - you could fall. The manufacturer is not responsible for damage on the product or for any damage that may occur while using this product. Scooter is intended for 1 rider only - no passengers! Not suitable for children under 3 years, contains small parts that the child may inhale. Speed reduction mechanisms (brake blocks, rims, etc.) heat up during use, do not touch them after use!

MAINTENANCE

It is recommended to entrust maintenance to specialized service. Regularly check, tighten, or adjust following parts: bolts connections, tightening mechanisms, lubricate sliding parts (wheel bearings, handlebar bearings etc.) check cables and brake parts. Before each use check tightening of all bolts and function of break. In case you notice wear of some parts (tires, bearings, breaking parts etc.) replace them with parts with same parameters and adjust them properly. Clean the scooter with aggressive cleaning agents, for bearings use oil for bikes. After use it is recommended to entrust tightening of wires evenly by specialized service.

WARNING: Breaking pads and rim must be protected against oil and grease.

If it starts to "crack" in the spokes while riding, it is necessary to tighten the spokes by 2 turns (entrust to a professional service), or lubricate, adjust or replace bearings and bearing parts. If it is necessary to change the wheels, always use wheels / tires with the same parameters as the original ones. Disassemble in the opposite way to installation (see Instructions). Have the tire and tube replaced or repaired by a specialist service. If the scooter's design contains self-locking nuts or other self-locking mechanisms, frequent loosening and tightening will result in loss of effectiveness. In this case replace them.

ENVIRONMENT PROTECTION

After the product lifespan expired or if the possible repairing is uneconomic, dispose it according to the local laws and environmentally friendly in the nearest scrapyard.

By proper disposal you will protect the environment and natural sources. Moreover, you can help protect human health. If you are not sure in correct disposing, ask local authorities to avoid law violation or sanctions.

Don't put the batteries among house waste but hand them in to the recycling place.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated here under determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 89/2012 Coll. Civil Code, and Act No. 634/1992 Coll., Consumer Protection, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Strakonická street 1151/2c, Prague 150 00, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

"The Buyer who is the End Customer" or simply the "End Customer" is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

"The Buyer who is not the End Customer" is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages

- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints, wear of brake pads/blocks, chain, tires, cassette/multi wheel etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.

CZ

SEVEN SPORT s.r.o.

Registered Office: Strakonická 1151/2c, Praha 5, 150 00, ČR
Headquarters: Dělnická 957, Vítkov, 749 01
Warranty & Service: Čermenská 486, Vítkov 749 01

CRN: 26847264
VAT ID: CZ26847264

Phone: +420 556 300 970
E-mail: eshop@insportline.cz
reklamace@insportline.cz
servis@insportline.cz

Web: www.inSPORTline.cz

SK

inSPORTline s.r.o.

Headquarters, warranty & service center: Električná 6471, Trenčín 911 01, SK

CRN: 36311723
VAT ID: SK2020177082

Phone: +421(0)326 526 701
E-mail: objednavky@insportline.sk

reklamacie@insportline.sk
servis@insportline.sk
www.inSPORTline.sk

Web: