



USER MANUAL – EN

IN 13247 Scooter WORKER Cirky with Light-Up Wheels

IN 13249 Scooter WORKER Darky

IN 13250 Scooter WORKER Blancy



CONTENTS

UNFOLDING..... 3
RIDE INSTRUCTIONS 3
FOLDING..... 3
SAFETY PRECAUTIONS..... 3
STORING AND MAINTENANCE 4
TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS..... 4


According to the standard EN 14619 the scooters are divided in two categories:

Category	Max. user weight
A	100 kg
B	50 kg

Follow instructions on each product.

UNFOLDING

- Release lever of the folding mechanism (Pic. 1).
- Hold the fork with both hands so that your thumbs are on the fork. Your index fingers should be on the front stem (Pic. 2).
- Push the fork to yourself and use the index fingers to lift the stem (Pic. 2).
- Hold it in raised position using your right hand (Pic. 3).
- Secure the lever of folding mechanism.
- Insert grips into handlebars – securing pins should go through the handlebar holes (Pic. 4).
- Release the handlebar fastener and adjust the handlebars in required height. Secure it again (Pic. 5).




RIDE INSTRUCTIONS

- Check that this device is properly assembled before each using.
- Hold the grips firmly while riding.
- One foot is on the board and the second foot pushes off the ground.
- To turn, move the handlebars in required direction. To stop, step on the rear brake.
- The braking mechanism gets hot during using. Don't touch it with naked skin.

FOLDING

- Release the handlebar fastener and put the handlebars into the lowest position.
- Secure the fastener again.
- Push the pins and remove grips out from the handlebar.
- Release lever of the folding mechanism.
- Use your thumb and your left index finger to hold the fork. Fold the rear stem with your right hand (Pic. 7).
- Hold the stem all the time to avoid finger crushing.
- Secure lever of the folding mechanism (Pic. 8).



SAFETY PRECAUTIONS

- Read this manual before first using and retain it for future reference.
- Children may use it only under adult supervision. Assembly should be done only by an adult.

- Pay attention during folding to avoid an injury.
- Use it only in safe places and avoid traffic. Ride only on a flat, clean and dry surface. Never violate local laws and regulations.
- Check that all bolts, nuts and components are well tightened before each riding and that this device is properly assembled and secured.
- We recommend using protective garments such as: helmet, protectors of knees, elbows, wrists etc.
- Don't jump over obstacles.
- Observe traffic rules and respect pedestrians.
- Never disassemble the brake.
- Don't ride in rain, in poor visibility or at night.
- Always hold the handlebars with both hands.
- Never ride barefoot.
- Maintain it properly and regularly. Don't do any improper modification. Regularly check wheels and bearings for damage or wearing. Replace if necessary. Quick-release and self-locking systems can lose effectiveness with time. Check them as well.

STORING AND MAINTENANCE

- Check that all screws and nuts are properly tightened before each usage. Check wheels and handlebars as well.
- Lubricate bearings and joints regularly.
- Never use solvents to clean it and protect it from humidity. Store it only in a dry and clean place.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated hereunder determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 40/1964 Coll. Civil Code, Act No. 513/1991 Coll., Commercial Code, and Act No. 634/1992 Coll., Consumer Protection Act, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Borivojova Street 35/878, Prague 13000, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions to the extent specified in the Commercial Code.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.



SEVEN SPORT s.r.o.

Registered Office:

Borivojova 35/878, 130 00 Praha 3, Czech Republic

Headquarters:

Delnicka 957, 749 01 Vitkov, Czech Republic

Warranty & Service Centre:

Cermenska 486, 749 01 Vitkov, Czech Republic

CRN: 26847264
VAT ID: CZ26847264
Phone: +420 556 300 970
E-mail: eshop@insportline.cz
reklamace@insportline.cz
servis@insportline.cz
Web: www.insportline.cz

SK

INSPORTLINÉ s.r.o.

Headquarters, Warranty & Service centre: Elektrická 6471, 911 01 Trenčín, Slovakia

CRN: 36311723

VAT ID: SK2020177082

Phone: +421(0)326 526 701
E-mail: objednavky@insportline.sk
reklamacie@insportline.sk
servis@insportline.sk
Web: www.insportline.sk

Date of Sale:

Stamp and Signature of Seller: