



USER MANUAL – EN
IN 13251 Scooter WORKER Span



CONTENTS

SAFETY PRECAUTIONS3
COMPONENTS.....4
CONSTRUCTION5
 ASSEMBLING5
 FOLDING5
MAINTENANCE.....6
TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS6

SAFETY PRECAUTIONS

Check the scooter before every ride. You must hear the click sound during assembling adjustable tube, hand grips and folding mechanism. "

NOTE: The brake heats up due to braking, do not touch the brake immediately.

- This product is not a toy. It is sport equipment for leisure time and sports.
- Braking: push down the brake with your foot.
- Most accidents occur at the beginning and during first month of use. Be careful and do not overestimate your abilities.
- Always wear protective equipment: helm, knee and elbow protectors and protective gloves.
- Only one person can use the product at the time.
- Follow local regulations and laws.
- Try to avoid riding in crowded places.
- Do not ride on wet and slippery surface.
- Use sport shoes.
- Do not modify or adjust the scooter. This scooter is not made for jumping over obstacles or acrobatics.
- Pay extra attention when riding near people.
- We do not recommend using the scooter in dark or dusk.
- Maximum load: 100 KG
- According to EN 14619 standard.

COMPONENTS

This scooter provides easy manipulation and can be used almost everywhere: it can be folded in a moment for easy transportation or storage. It is fast and ecological mean of transport, which will transport you in time to your desirable place, without the threatening the environment. Thank you for purchasing this product, which can be described as a mean of transport for the future.



1. Hand grip
2. Hand grip holder
3. Spring handlebar pin
4. Brake / fender
5. Folding mechanism
6. Spring hand grip pins
7. Handlebar
8. Handle lever
9. Control rod

Please follow installation instructions, to minimize risk of injury associated with the assembly / disassembly of the scooter (for example: fingers injuries).

CONSTRUCTION

ASSEMBLING

A. Opening the scooter

Loosen the folding mechanism (5) and lift the control rod (9), until you hear the click sound of the lock – this will automatically secure the folding mechanism (5).

B. Hand grips

Remove the hand grips (1) from plastic grips and slide them into handlebar (7) until you hear the click sound of the lock. Check that Spring hand grip pins (6) have passed the holes in the handlers.

In scooters with suspension remove the quick-release lever and follow the instructions below.

C. Adjust height

Open the handle lever (8), and setup the height (you will hear the click sound when securing the handlebar) and then close the handle lever (8).



FOLDING

D. Lowering the handlebar

Open the handle lever (8) on the handlebar, and press the spring handlebar pin (3). Then lower the handlebar to lowest position. After that close the handle lever (8).

E. Removing the hand grips

Press the spring hand grips pin (6) from hand grips (1), and then slide out the handle grips from handlebar (7) and put them into plastic grips.

F. Folding the control rod

Loosen the folding mechanism (5) and push the control rod (9), until you hear the click sound of the safety pin – this will automatically secure the folding mechanism (5).



MAINTENANCE

- Regularly check that all tightening parts are fasten properly – especially wheels bolts, folding mechanism, brake, handlebar and suspension. These parts can be loose after usage.
- Use only original spare parts.
- Remove any sharp object on the scooter.
- Store the scooter in dry and clean place.
- Do not try to modify any part of the scooter such as brake, control rod, folding mechanism etc.



Regularly check the bearing and wheels, replace them if it is necessary.

TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated hereunder determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 40/1964 Coll. Civil

Code, Act No. 513/1991 Coll., Commercial Code, and Act No. 634/1992 Coll., Consumer Protection Act, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Borivojova Street 35/878, Prague 13000, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions to the extent specified in the Commercial Code.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

Warranty Conditions

Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.



SEVEN SPORT s.r.o.

Registered Office:	Borivojova 35/878, 130 00 Praha 3, Czech Republic
Headquarters:	Delnicka 957, 749 01 Vitkov, Czech Republic
Warranty & Service Centre:	Cermenska 486, 749 01 Vitkov, Czech Republic
CRN:	26847264
VAT ID:	CZ26847264
Phone:	+420 556 300 970
E-mail:	eshop@insportline.cz reklamace@insportline.cz servis@insportline.cz
Web:	www.insportline.cz

SK

INSPORTLIN s.r.o.

Headquarters, Warranty & Service centre:	Elektricka 6471, 911 01 Trenčin, Slovakia
CRN:	36311723
VAT ID:	SK2020177082
Phone:	+421(0)326 526 701
E-mail:	objednavky@insportline.sk reklamacie@insportline.sk servis@insportline.sk
Web:	www.insportline.sk

Date of Sale:

Stamp and Signature of Seller: