

USER MANUAL – EN

IN 27836 Crampons inSPORTline Grint

SevenSport s.r.o. reserves the right to make any changes and improvements to its product without prior notice. Visit our website www.insportline.eu where you will find the latest version of the manual.

SAFETY INSTRUCTIONS

- Use at your own risk. The seller is not responsible for any damage to other people's property or personal injury. Decorative object. If you decide to use crampons, be sure to follow all the information below:
- Functionality is ensured only if the product is fitted correctly, and the correct size of non-slips is used according to the size of the shoe.
- If the product is damaged or shows visible signs of wear, stop using it immediately.
- Do not modify the product.
- The product is not intended for mountain climbing or other extreme sports.
- The product is only suitable for incline of up to 20°.
- Appropriate use must always be evaluated by the user at his own risk.
- Before use, always check the integrity of the product for damage or wear. Spikes must be firmly attached to the shoe. Check during use.
- Always test the application on the surface for which you want to use the product.
- The product is suitable for surfaces: ice, snow, soft and slippery surfaces.
- The product must not be used on surfaces: stone, rocks, asphalt, tiles, wooden floors, parquet and other hard surfaces. Do not use indoors, you may damage the floor surface and risk slipping.
- Not suitable while driving. Keep out of reach of children and animals.
- Always transport in the supplied shipping bag and use protective gloves for handling.
- After use, clean with lukewarm water and a mild detergent. Dry properly. Store in a dry and well-ventilated place, away from heat or sunlight.
- Load capacity: 200 kg

USE

1. Place the crampons on the toe of the shoe. 2. Place the crampons on the heel so that the lower part with the spikes is tight. 3. Pull and loop strap through the fixed part of the crampons through the metal eyelet on the strap. 4. Pull the Velcro on the other side of the crampons. 5. Secure the Velcro and check the tightness of the chains to the shoe. 6. Done.



CZ SEVEN SPORT s.r.o.

Registered Office: Strakonická 1151/2c, Praha 5, 150 00, ČR
Headquarters: Dělnická 957, Vítkov, 749 01
Warranty & Service: Čermenská 486, Vítkov 749 01

CRN: 26847264
VAT ID: CZ26847264

Phone: +420 556 300 970
E-mail: eshop@insportline.cz
reklamace@insportline.cz
servis@insportline.cz

Web: www.inSPORTline.cz

SK Stores inSPORTline SK, s.r.o.

Headquarters, warranty & service center: Električná 6471, Trenčín 911 01, SK

CRN: 46259317
VAT ID: SK2023299729

Phone: +421(0) 917 700 098
E-mail: objednavky@insportline.sk
reklamacie@insportline.sk
servis@insportline.sk

Web: www.inSPORTline.sk

About shipping



Material: 40% silicone, 60% stainless steel