



**USER MANUAL – EN**  
**IN 7323 Massage Seat inSPORTline D24**



## CONTENTS

SAFETY INSTRUCTIONS.....	3
CONTROLS.....	4
PRODUCT SPECIFICATION .....	5
TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS.....	6

Ultra-thin, luxury and with two sets of massage cushions based on humanistic design. It has features of kneading and massaging to eliminate fatigue. It offers massaging speed options of strong, medium and weak, so it feels like being massaged under professional masseurs. The cushion can be used in the car and at home conveniently and comfortably.

#### **Luxury massage seat has two types of massages**

- Kneading and vibration massage.
- Three kinds of kneading massages for your back.
- Massage with Blue-ray and infrared rays
- Professional vibration massage on your thigh.
- Hand controller
- Easy to tie on many kinds of chairs.
- Indoor and car use.



Thanks for purchasing this product. Please read this manual instruction carefully in order to know how to use this product correctly. Please pay to important safety warning and keep this manual for future use.

Note: Our Company reserves the right to revise the design and description of this product without any further notice. Please refer to the actual color of this product.

## **SAFETY INSTRUCTIONS**

- Don't put the finger into the space between the cover and the massage head while it's working.
- Please don't drop anything into this product.
- Keep away from water to avoid electric shock or cause damage to this product.
- If the wire or the plug are broken ask professional for help.
- Please contact your supplier for maintenance.
- Please use well-grounding power supply suitable for this product.
- Please pull out the plug after use or before cleaning to avoid injury or damage of the product.
- Please operate this product according to this manual.
- Don't use accessories which are not recommended. Do not modify the product.
- Don't use this product outdoors.
- Please don't use it if the cover or leather is damaged.
- Please don't use the product when you are under influence of drugs or alcohol.
- Do not use the product if you feel sick or dizzy.
- Please don't make the massage function too strong for avoiding injury.
- Do not use in high temperatures or in moist places such as bathroom.
- Do not use when the temperature is changing rapidly.
- Do not use in dust heavy environment.

- People who are not suitable to use this product:
  - People suffering from skin disease
  - People suffering from osteoporosis
  - People suffering hearth problems or using electrical medical equipment
  - People suffering from fever
  - Pregnant women
  - Children under 14-years old or people with reduced mental or physical capabilities
  - People who are restricted to use this product from doctor
  - People with wet bodies
  - People sensitive to heat
- Do not pull the plug with wet hands.
- Do not pull the plug by pulling the power cord.
- Do not damage the wires
- Stay away from product to reduce risk of injury when there is a power cut.
- Stop using the product if it is not working properly or is damaged.
- If you feel sick when using this product stop using it and contact, you physician immediately.
- If the power adapter is damaged contact your supplier or other professional for repair.
- Keep away from pets and kids.
- People with reduced mental or physical capabilities, people who lack experience and knowledge or kid should use this product under adult supervision.

The set includes: moving kneading structure, two vibrating motors, hand controller, PCB driver, power adapter and automobile theft device

## CONTROLS

- Plug to the socked and press POWER button. The power indicator will turn on (if the red indicator flickers the massage heads are not in right positions. Move the massage heads to the right position to stop the indicator flickering) and the device will come to standby mode. Press the POWER button again to turn off the device.
- In standby mode you can press and function button to start massage mode.
- To turn off the device press the POWER button. The power indicator will start to flicker, and the vibration motor will stop working. The kneading function will stop. The power indicator will turn off if the device is off.
- If the device is not used for more than 15 minutes it will automatically turn off.
- Function key work only in work or standby mode. The function buttons do not work in DEMO mode.

	<p><b>Vibration keys</b></p> <ol style="list-style-type: none"> <li>1. Two groups of massage heads are set inside to massage your thighs</li> <li>2. <b>VIBRATION MODE:</b> There are four options for vibration mode: mode 1, mode 2, mode 3 and stop. Every time you press the SKILL button it will change to different mode.</li> <li>3. <b>STRENGTH:</b> This button is working only when the massage is in progress. There are three options: strong, medium, weak</li> </ol> <p><b>Kneading buttons</b></p> <ol style="list-style-type: none"> <li>1. <b>FULL BODY:</b> When you press the button, the indicator will turn on. The kneading heads will move up and down on your back.</li> <li>2. <b>UPPER:</b> When you press the button, the indicator will turn on. The kneading heads will focus on middle and lower back.</li> <li>3. <b>LOWER:</b> When you press the button, the indicator will turn on. The kneading heads will focus on lower and middle parts of back.</li> </ol> <p><b>Demo key</b></p> <p>Use this button for demonstration of massages. It will provide short 9 combinations of massages, 3 kinds of vibrations and 3 kinds of strength. When the demo is completed the product will automatically turn off.</p>
--	---

## PRODUCT SPECIFICATION

**Model:** SL-D24

**Configure:** 01

**Rated voltage:** 12 V

**Rated power input:** 25 W

**Rated working time:** 15 min



# TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

## General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated hereunder determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 40/1964 Coll. Civil Code, Act No. 513/1991 Coll., Commercial Code, and Act No. 634/1992 Coll., Consumer Protection Act, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Borivojova Street 35/878, Prague 13000, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions to the extent specified in the Commercial Code.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

## Warranty Conditions

### Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

### The Warranty does not cover defects resulting from (if applicable):

- User's fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks
- Improper maintenance
- Mechanical damages
- Regular use (e.g. wearing out of rubber and plastic parts, moving mechanisms, joints etc.)
- Unavoidable event, natural disaster
- Adjustments made by unqualified person
- Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

## Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product's serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

If the Buyer gives notice of a defect that is not covered by the Warranty (e.g. in the case that the Warranty Conditions were not fulfilled or in the case of reporting the defect by mistake etc.), the Seller is eligible to require a compensation for all the costs arising from the repair. The cost shall be calculated according to the valid price list of services and transport costs.

If the Seller finds out (by testing) that the product is not damaged, the Warranty Claim is not accepted. The Seller reserves the right to claim a compensation for costs arising from the false Warranty Claim.

In case the Buyer makes a claim about the Goods that is legally covered by the Warranty provided by the Seller, the Seller shall fix the reported defects by means of repair or by the exchange of the damaged part or product for a new one. Based on the agreement of the Buyer, the Seller has the right to exchange the defected Goods for a fully compatible Goods of the same or better technical characteristics. The Seller is entitled to choose the form of the Warranty Claim Procedures described in this paragraph.

The Seller shall settle the Warranty Claim within 30 days after the delivery of the defective Goods, unless a longer period has been agreed upon. The day when the repaired or exchanged Goods is handed over to the Buyer is considered to be the day of the Warranty Claim settlement. When the Seller is not able to settle the Warranty Claim within the agreed period due to the specific nature of the Goods defect, he and the Buyer shall make an agreement about an alternative solution. In case such agreement is not made, the Seller is obliged to provide the Buyer with a financial compensation in the form of a refund.



**SEVEN SPORT s.r.o.**

Registered Office:	Borivojova 35/878, 130 00 Praha 3, Czech Republic
Headquarters:	Delnicka 957, 749 01 Vitkov, Czech Republic
Warranty & Service Centre:	Cermenska 486, 749 01 Vitkov, Czech Republic
CRN:	26847264
VAT ID:	CZ26847264
Phone:	+420 556 300 970
E-mail:	eshop@insportline.cz reklamace@insportline.cz servis@insportline.cz
Web:	www.insportline.cz

---

**SK**

**INSPORTLIN s.r.o.**

Headquarters, Warranty & Service centre:	Elektricka 6471, 911 01 Trenčin, Slovakia
CRN: 36311723	
VAT ID: SK2020177082	
Phone:	+421(0)326 526 701
E-mail:	objednavky@insportline.sk reklamacie@insportline.sk servis@insportline.sk
Web:	www.insportline.sk

Date of Sale:

Stamp and Signature of Seller: