




**USER MANUAL – EN**


**IN 7602 Wireless Stereo Headset with Heart Rate Monitor  
inSPORTline Pulsate BP-7005**



**CONTENTS**

DESCRIPTION..... 3  
FUNCTIONS FOR BLUETOOTH HEADSET..... 3  
HEART RATE MONITOR ..... 4  
LED LIGHT INDICATOR ..... 4  
TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS ..... 5

## DESCRIPTION



- |                         |   |
|-------------------------|---|
| 1. LED Indicator        | 6. Power ON/OFF                             |
| 2. Skip Track Forward   | 7. Multifunction                            |
| 3. Volume +             | 8. 3.5mm interface for<br>heartrate monitor |
| 4. Volume -             | 9. MIC                                      |
| 5. Skip Track Backwards | 10. Micro USB Charging Port                 |

When the connection is successful, the blue LED of the headset will flash 3 times. Then blue LED will flash once every 7 seconds to indicate a device is connected.

Note: If the pairing is unsuccessful, please turn OFF the Headphones and then ON again and repeat the connection procedure.

## FUNCTIONS FOR BLUETOOTH HEADSET

Power on	In the off state, push switch button to “ON” position, blue light flash 3times and headset beeps.
Pair connect	In the off state, long press multifunction button for 7S until red and blue light flash alternately, using the mobile phone to search the Bluetooth device and connect, headset beeps.
Answer calls	When there is an incoming call, short press multifunction button and headset beeps.
Hang up calls	On the line, short press multifunction and headset beeps.
Refuse calls	When there is an incoming call, long press multifunction button for 3S and headset beeps.
Voice dial	On the standby state, long press multifunction button for 3S (need the mobile phone support this function)
Voice transfer	On the line, long press multifunction button for 3S, the voice switch to mobile phone. Using the same operation, the voice can switch to Bluetooth.
Redial the last dialed number	On the standby state, dual- click multifunction button and headset beeps.

Mic mute	On the line, long press multifunction button for 3S, red and blue light flash 2 times at the same time and the headset beeps, opposite can't hear the voice. same operate can recover microphone voice.
Line IN	/
Volume adjust	Short press the volume key (+) can increase the volume ,short press the volume (-) can decrease the volume (The maximum and minimum volume speaker beeps )
Play and pause	When play music, short press multifunction button can play/pause music
Last/next	When play music, long press volume (-) button 3S can play last one song, long press volume (+) button can play next one song.
Support two mobile phone connect	/
NFC pair	Nonsupport
Iphone battery status	Support
Exit the pairing mode automatically	Automatically quit out the pairing mode when there is no pairing finished within 5min
Auto power-off	Lost connection for 10minutes or the battery voltage below 3.2V
Manual shutdown	Power on connected/not connected state, long press the multifunction key 3seconds, red light flash 3times and headset beeps.

## HEART RATE MONITOR

1. Heart rate ear clip insert headphone and headset power on.
2. Take headphones in the head, the heart rate meter ear clip clip in the middle of the earlobe.
3. Start the heart rate monitor software on your phone.
4. In the fourth interface of the heart rate monitor click and search, search the heart rate monitor pairing address, and then click the address connection.
5. At this time back to the heart rate of the first interface, there will be a test of the heart rate display on the phone.
6. In the history page to view the history of the test.
7. The curve can view recent curve test show that page.

## LED LIGHT INDICATOR

Power on	Blue light flash 3 times quickly
Power off	Red light flash 2times quickly
Standby (not connect with mobile phone)	Blue light flash one time every 7S
Standby (connect with mobile phone)	Blue light flash one time every 5S
Calling in	Blue light flash one time every 1s
On the line	Blue light flash one time every 6S
Open mute	Blue and red light flash 2time at the same time
Charging	Red light flash long
Full charge	Red light die out

Low voltage alarm	Red light flash 2times every 30S
-------------------	----------------------------------

## TERMS AND CONDITIONS OF WARRANTY, WARRANTY CLAIMS

### General Conditions of Warranty and Definition of Terms

All Warranty Conditions stated hereunder determine Warranty Coverage and Warranty Claim Procedure. Conditions of Warranty and Warranty Claims are governed by Act No. 40/1964 Coll. Civil Code, Act No. 513/1991 Coll., Commercial Code, and Act No. 634/1992 Coll., Consumer Protection Act, as amended, also in cases that are not specified by these Warranty rules.

The seller is SEVEN SPORT s.r.o. with its registered office in Borivojova Street 35/878, Prague 13000, Company Registration Number: 26847264, registered in the Trade Register at Regional Court in Prague, Section C, Insert No. 116888.

According to valid legal regulations it depends whether the Buyer is the End Customer or not.

“The Buyer who is the End Customer” or simply the “End Customer” is the legal entity that does not conclude and execute the Contract in order to run or promote his own trade or business activities.

“The Buyer who is not the End Customer” is a Businessman that buys Goods or uses services for the purpose of using the Goods or services for his own business activities. The Buyer conforms to the General Purchase Agreement and business conditions to the extent specified in the Commercial Code.

These Conditions of Warranty and Warranty Claims are an integral part of every Purchase Agreement made between the Seller and the Buyer. All Warranty Conditions are valid and binding, unless otherwise specified in the Purchase Agreement, in the Amendment to this Contract or in another written agreement.

### Warranty Conditions

#### Warranty Period

The Seller provides the Buyer a 24 months Warranty for Goods Quality, unless otherwise specified in the Certificate of Warranty, Invoice, Bill of Delivery or other documents related to the Goods. The legal warranty period provided to the Consumer is not affected.

By the Warranty for Goods Quality, the Seller guarantees that the delivered Goods shall be, for a certain period of time, suitable for regular or contracted use, and that the Goods shall maintain its regular or contracted features.

#### The Warranty does not cover defects resulting from:

User’s fault, i.e. product damage caused by unqualified repair work, improper assembly, insufficient insertion of seat post into frame, insufficient tightening of pedals and cranks

Improper maintenance

Mechanical damages

Regular use (e.g. wearing out of rubber and plastic parts, joints etc.)

Unavoidable event, natural disaster

Adjustments made by unqualified person

Improper maintenance, improper placement, damages caused by low or high temperature, water, inappropriate pressure, shocks, intentional changes in design or construction etc.

### Warranty Claim Procedure

The Buyer is obliged to check the Goods delivered by the Seller immediately after taking the responsibility for the Goods and its damages, i.e. immediately after its delivery. The Buyer must check the Goods so that he discovers all the defects that can be discovered by such check.

When making a Warranty Claim the Buyer is obliged, on request of the Seller, to prove the purchase and validity of the claim by the Invoice or Bill of Delivery that includes the product’s serial number, or eventually by the documents without the serial number. If the Buyer does not prove the validity of the Warranty Claim by these documents, the Seller has the right to reject the Warranty Claim.

